

CommandName	CommandId	Shortcuts	Paths
Modify	ID_BUTTON_SELECT	MD	Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Select links	ID_TOGGLE_ALLOW_LINK_SELECTION		Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Select underlay elements	ID_TOGGLE_ALLOW_UNDERLAY_SELECTION		Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Select pinned elements	ID_TOGGLE_ALLOW_PINNED_SELECTION		Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Select elements by face	ID_TOGGLE_ALLOW_FACE_SELECTION		Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Drag elements on selection	ID_TOGGLE_ALLOW_DRAG_ON_SELECTION		Create>Select; Insert>Select; Annotate>Select; View>Select; Manage>Select; Modify>Select; Architectural
Type Properties	Dialog_Revit_FamilyBar:Control_Revit_PropertyPanelTypePropBtn		Create>Properties; Modify>Properties
Properties; Toggle Properties Palette	ID_TOGGLE_PROPERTIES_PALETTE	PP#Ctrl+1#VP	Create>Properties; View>Windows; Modify>Properties; Contextual Tabs>Properties
Family Category and Parameters	ID_OBJECTS_FAMILYHOST		Create>Properties; Modify>Properties
Family Types	ID_FAMILY_TYPE		Create>Properties; Modify>Properties
Solid Extrusion	ID_OBJECTS_EXTRUSION		Create>Forms
Solid Blend	ID_OBJECTS_BLEND		Create>Forms
Solid Revolve	ID_OBJECTS_REVOLUTION		Create>Forms
Solid Sweep	ID_OBJECTS_SWEEP		Create>Forms
Solid Swept Blend	ID_OBJECTS_SWEPTBLEND		Create>Forms
Void Forms:Void Extrusion	ID_OBJECTS_EXTRUSION_CUT		Create>Forms
Void Forms:Void Blend	ID_OBJECTS_BLEND_CUT		Create>Forms
Void Forms:Void Revolve	ID_OBJECTS_REVOLUTION_CUT		Create>Forms
Void Forms:Void Sweep	ID_OBJECTS_SWEEP_CUT		Create>Forms
Void Forms:Void Swept Blend	ID_OBJECTS_SWEPTBLEND_CUT		Create>Forms
Model Line; Model Line; Boundary Line; Rebar Line	ID_OBJECTS_CURVE	LI	Create>Model; Create>Detail; Create>Draw; Modify>Draw; Contextual Tabs>Draw
Place a Component	ID_OBJECTS_FAMSYM	CM	Create>Model; Architecture>Build; Structure>Model; Systems>Model
Model Group:Place Model Group	ID_OBJECTS_PLACE_GROUP		Create>Model; Architecture>Model; Structure>Model
Model Group:Create Group; Detail Group:Create Group	ID_EDIT_GROUP	GP	Create>Model; Annotate>Detail; Modify>Create; Create>Detail; Architecture>Model; Structure>Model
Model Text	ID_OBJECTS_MODELTEXT		Create>Model; Architecture>Model; Structure>Model
Opening	ID_OBJECTS_OPENING		Create>Model
Control	ID_OBJECTS_CONTROL		Create>Control
Electrical Connector; Electrical Connector	ID_RBS_ADD_ELECTRICAL_CONNECTOR		Create>Connectors
Duct Connector; Duct Connector	ID_RBS_ADD_DUCT_CONNECTOR		Create>Connectors
Pipe Connector; Pipe Connector	ID_RBS_ADD_PIPE_CONNECTOR		Create>Connectors
Cable Tray Connector; Cable Tray Connector	ID_RBS_ADD_CABLETRAY_CONNECTOR		Create>Connectors
Conduit Connector; Conduit Connector	ID_RBS_ADD_CONDUIT_CONNECTOR		Create>Connectors
Reference Line; Reference Line	ID_OBJECTS_REFERENCE_CURVE		Create>Datum; Create>Draw; Modify>Draw
Reference Plane; Reference Plane	ID_OBJECTS_CLINE	RP	Create>Datum; Create>Draw; Modify>Draw; Architecture>Work Plane; Structure>Work Plane; Systems>
Set Work Plane	ID_SKETCH_PLANE_TOOL		Create>Work Plane; Modify>Work Plane; Architecture>Work Plane; Structure>Work Plane; Systems>
Show Work Plane	ID_SKETCH_GRID_VIS		Create>Work Plane; Modify>Work Plane; Architecture>Work Plane; Structure>Work Plane; Systems>
Workplane Viewer; Form Work Plane View	ID_WORKPLANE_VIEW		Create>Work Plane; Modify>Work Plane; Architecture>Work Plane; Structure>Work Plane; Systems>
Link Revit	ID_RVTDOC_LINK		Insert>Link
Link IFC	ID_IFC_LINK		Insert>Link
Link CAD	ID_FILE_CADFORMAT_LINK		Insert>Link
DWF Markup	ID_MARKUPS_LOAD		Insert>Link
Decal; Place Decal	ID_RM_CREATE_DECAL		Insert>Link
Decal:Decal Types; Decal Types	ID_SETTINGS_DECAL_TYPES		Insert>Link; Manage>Manage Project
Point Cloud	ID_POINT_CLOUD		Insert>Link
Manage Links	ID_LINKED_DWG		Insert>Link; Manage>Manage Project; Contextual Tabs>Link
Import CAD	ID_FILE_IMPORT		Insert>Import
Import gbXML	ID_ABS_IMPORT_GBXML		Insert>Import
Insert from File:Insert Views from File	ID_INSERT_VIEWS_FROM_FILE		Insert>Import
Insert from File:Insert 2D Elements from File	ID_INSERT_2D_ELEMENTS_FROM_FILE		Insert>Import
Image	ID_OBJECTS_RASTER		Insert>Import
Manage Images	ID_EDIT_RASTER_SYMBOLS		Insert>Import; Manage>Manage Project
Import Family Types; Import Types...	ID_IMPORT_FAM_TYPES		Insert>Import
Load Family; Load Framing Family; Load Shapes	ID_FAMILY_LOAD		Insert>Load from Library; Contextual Tabs>Mode; Contextual Tabs>Family

Load as Group	ID_LOAD_GROUP		Insert>Load from Library
Search Seek Online	IDC_CONTENT_SEARCH		Insert>Autodesk Seek
Aligned Dimension	ID_ANNOTATIONS_DIMENSION_ALIGNED	DI	Annotate>Dimension; Modify>Measure; Create>Dimension; Contextual Tabs>Dimension; Quick Access Toolbar
Angular Dimension	ID_ANNOTATIONS_DIMENSION_ANGULAR		Annotate>Dimension; Modify>Measure; Create>Dimension; Contextual Tabs>Dimension
Radial Dimension	ID_ANNOTATIONS_DIMENSION_RADIAL		Annotate>Dimension; Modify>Measure; Create>Dimension; Contextual Tabs>Dimension
Diameter Dimension	ID_ANNOTATIONS_DIMENSION_DIAMETER		Annotate>Dimension; Modify>Measure; Create>Dimension; Contextual Tabs>Dimension
Arc Length Dimension	ID_ANNOTATIONS_DIMENSION_ARCLENGTH		Annotate>Dimension; Modify>Measure; Create>Dimension; Contextual Tabs>Dimension
Linear Dimension Types	ID_SETTINGS_DIMENSIONS_LINEAR		Annotate>Dimension; Create>Dimension
Angular Dimension Types	ID_SETTINGS_DIMENSIONS_ANGULAR		Annotate>Dimension; Create>Dimension
Radial Dimension Types	ID_SETTINGS_DIMENSIONS_RADIAL		Annotate>Dimension; Create>Dimension
Diameter Dimension Types	ID_SETTINGS_DIMENSIONS_DIAMETER		Annotate>Dimension; Create>Dimension
Symbolic Line	ID_OBJECTS_VIEW_DIR_SPEC_CURVE		Annotate>Detail
Detail Component; Detail Component	ID_OBJECTS_FAMDETAIL		Annotate>Detail; Create>Detail
Detail Group;Place Detail Group	ID_OBJECTS_PLACE_DETAIL_GROUP		Annotate>Detail; Create>Detail
Symbol	ID_OBJECTS_FAM_ANN_INST		Annotate>Detail; Create>Detail; Annotate>Symbol
Masking Region; Masking Region	ID_MASKING_REGION		Annotate>Detail; Create>Detail
Text	ID_OBJECTS_TEXT_NOTE	TX	Annotate>Text; Create>Text; Quick Access Toolbar
Check Spelling	ID_CHECK_SPELLING		Annotate>Text; Create>Text; Contextual Tabs>Tools
Find/ Replace	ID_FIND_REPLACE	FR	Annotate>Text; Create>Text; Contextual Tabs>Tools
Visibility/ Graphics	ID_VIEW_CATEGORY_VISIBILITY	VG#VV	View>Graphics
Thin Lines; Thin Lines	ID_THIN_LINES	TL	View>Graphics; Quick Access Toolbar
3D View; Default 3D View	ID_VIEW_DEFAULT_3DVIEW		View>Create; Quick Access Toolbar
3D View:Camera; Default 3D View:Camera	ID_VIEW_NEW_3DVIEW		View>Create; Quick Access Toolbar
3D View:Walkthrough; Default 3D View:Walkthrough	ID_VIEW_NEW_WALKTHROUGH		View>Create; Quick Access Toolbar
Section	ID_VIEW_NEW_SECTION		View>Create; Quick Access Toolbar
Plan Region; Plan Views:Plan Region	ID_NEW_PLAN_REGION		View>Create
Plan Views:Floor Plan; Floor Plan	ID_VIEW_NEW_PLAN		View>Create
Plan Views:Reflected Ceiling Plan	ID_VIEW_NEW_RCP		View>Create
Plan Views:Structural Plan; Structural Plan	ID_VIEW_NEW_STRUCTURAL_PLAN		View>Create
Plan Views:Area Plan; Area:Area Plan	ID_VIEW_NEW_AREAScheme		View>Create; Architecture>Room & Area
Elevation; Elevation:Framing Elevation	ID_BUTTON_BRACING_ELEVATION		View>Create
Elevation:Building Elevation	ID_BUTTON_INTERIOR_ROOM_ELEVATION		View>Create
Duplicate View:Duplicate View	ID_PRJBROWSER_COPY		View>Create
Duplicate View:Duplicate with Detailing	ID_DUPLICATE_WITH_DETAILING		View>Create
Duplicate View:Duplicate as Dependent	ID_CREATE_DEPENDENT_VIEW		View>Create
Legends:Legend	ID_VIEW_NEW_LEGEND		View>Create
Legends:Keynote Legend	ID_VIEW_NEW_KEYNOTE_LEGEND		View>Create
Schedules:Schedule/Quantities; Schedule/ Quantities	ID_VIEW_NEW_SCHEDULE		View>Create; Analyze>Reports & Schedules
Schedules:Graphical Column Schedule	ID_VIEW_NEW_GRAPH_SCHED_COLUMN		View>Create
Schedules:Material Takeoff	ID_VIEW_NEW_MATERIAL_TAKEOFF		View>Create
Schedules:Sheet List	ID_VIEW_NEW_DRAWING_LIST		View>Create
Schedules:Note Block	ID_VIEW_NEW_NOTE_BLOCK		View>Create
Schedules:View List	ID_NEW_VIEWLIST		View>Create
Close Hidden Windows	ID_WINDOW_CLOSE_HIDDEN		View>Windows; Quick Access Toolbar
Replicate Window	ID_WINDOW_NEW		View>Windows
Cascade Windows	ID_WINDOW_CASCADE	WC	View>Windows
Tile Windows	ID_WINDOW_TILE_VERT	WT	View>Windows
ViewCube	ID_SHOW_VIEWCUBE		View>Windows
Navigation Bar	ID_NAVIGATION_BAR		View>Windows
Project Browser	ID_VIEW_PROJECTEXPLORER		View>Windows
System Browser	ID_RBS_SYSTEM_NAVIGATOR	Fn9	View>Windows
Status Bar	ID_VIEW_STATUS_BAR		View>Windows
Status Bar - Worksets	ID_STATUSBAR_WORKSETS		View>Windows
Status Bar - Design Options	ID_STATUSBAR_DESIGNOPTIONS		View>Windows

Recent Files	ID_STARTUP_PAGE		View>Windows
Browser Organization	ID_BROWSER_ORGANIZATION		View>Windows
Keyboard Shortcuts	ID_KEYBOARD_SHORTCUT_DIALOG	KS	View>Windows
Materials	ID_SETTINGS_MATERIALS		Manage>Settings
Object Styles	ID_SETTINGS_OBJECTSTYLES		Manage>Settings
Snaps	ID_SETTINGS_SNAPPING		Manage>Settings
Project Units	ID_SETTINGS_UNITS	UN	Manage>Settings
Shared Parameters	ID_FILE_EXTERNAL_PARAMETERS		Manage>Settings
Transfer Project Standards	ID_TRANSFER_PROJECT_STANDARDS		Manage>Settings
Purge Unused	ID_PURGE_UNUSED		Manage>Settings
Structural Settings	ID_STRUCTURAL_SETTINGS		Manage>Settings
MEP Settings:Load Classifications	ID_RBS_ELECTRICAL_LOAD_CLASSIFICATION		Manage>Settings
MEP Settings:Demand Factors	ID_RBS_ELECTRICAL_DEMAND_FACTOR		Manage>Settings
Panel Schedule Templates:Manage Templates	ID_RBS_PANEL_SCHEDULE_MANAGE_TEMPLATES		Manage>Settings
Panel Schedule Templates:Edit a Template	ID_RBS_PANEL_SCHEDULE_EDIT_A_TEMPLATE		Manage>Settings
Additional Settings:Fill Patterns	ID_SETTINGS_FILLPATTERNS		Manage>Settings
Additional Settings:Analysis Display Styles	ID_SETTINGS_ANALYSIS_DISPLAY_STYLES		Manage>Settings
Additional Settings:Line Styles	ID_SETTINGS_LINE_STYLES		Manage>Settings
Additional Settings:Line Weights	ID_SETTINGS_PENS		Manage>Settings
Additional Settings:Line Patterns	ID_SETTINGS_PEN_FONTS		Manage>Settings
Additional Settings:Section Tags	ID_VIEWTAGSTYLES_SECTIONTAGS		Manage>Settings
Additional Settings:Arrowheads	ID_SETTINGS_ANNOTATIONS_LEADERS		Manage>Settings
Additional Settings:Temporary Dimensions	ID_SETTINGS_DIMENSIONS		Manage>Settings
Additional Settings:Keynoting Settings	ID_SETTINGS_KEYNOTING		Manage>Settings; Annotate>Tag
Additional Settings:Detail Level	ID_DETAIL_LEVEL		Manage>Settings
Additional Settings:Assembly Code	ID_SETTINGS_ASSEMBLY_CODE		Manage>Settings
Starting View	ID_STARTING_VIEW		Manage>Manage Project
IDs of Selection	ID_IDS_OF_SELECTION		Manage>Inquiry
Select by ID	ID_SELECT_BY_ID		Manage>Inquiry
Review Warnings	ID_REVIEW_WARNINGS		Manage>Inquiry
Macro Manager	ID_TOOLS_MACROS		Manage>Macros
Macro Security	ID_TOOLS_MACROSECURITY		Manage>Macros
Paste; Paste from Clipboard	ID_EDIT_PASTE		Modify>Clipboard
Paste:Aligned to Selected Levels	ID_EDIT_PASTE_ALIGNED_LEVEL_BY_NAME		Modify>Clipboard
Paste:Aligned to Selected Views	ID_EDIT_PASTE_ALIGNED_VIEWS_BY_NAME		Modify>Clipboard
Paste:Aligned to Current View	ID_EDIT_PASTE_ALIGNED		Modify>Clipboard
Paste:Aligned to Same Place	ID_EDIT_PASTE_ALIGNED_SAME_PLACE		Modify>Clipboard
Paste:Aligned to Picked Level	ID_EDIT_PASTE_ALIGNED_PICK_LEVEL		Modify>Clipboard
Cut to Clipboard	ID_EDIT_CUT		Modify>Clipboard
Copy to Clipboard	ID_EDIT_COPY		Modify>Clipboard
Match Type Properties	ID_EDIT_MATCH_TYPE	MA	Modify>Clipboard
Paint	ID_EDIT_PAINT	PT	Modify>Geometry
Paint:Remove Paint	ID_EDIT_UNPAINT		Modify>Geometry
Cope; Apply Coping	ID_COPING	CP	Modify>Geometry
Cope:Remove Coping	ID_UNCOPING	RC	Modify>Geometry
Cut; Cut Geometry	ID_CUT_HOST		Modify>Geometry
Cut:Uncut Geometry	ID_UNCUT_HOST		Modify>Geometry
Join; Join Geometry	ID_JOIN_ELEMENTS_EDITOR		Modify>Geometry
Join:Unjoin Geometry	ID_UNJOIN_ELEMENTS_EDITOR		Modify>Geometry
Split Face	ID_SPLIT_FACE	SF	Modify>Geometry
Align	ID_ALIGN	AL	Modify>Modify
Move	ID_EDIT_MOVE	MV	Modify>Modify
Offset	ID_OFFSET	OF	Modify>Modify
Copy	ID_EDIT_MOVE_COPY	CO#CC	Modify>Modify

Mirror - Pick Axis	ID_EDIT_MIRROR	MM	Modify>Modify
Rotate	ID_EDIT_ROTATE	RO	Modify>Modify
Mirror - Draw Axis	ID_EDIT_MIRROR_LINE	DM	Modify>Modify
Trim/Extend to Corner	ID_TRIM_EXTEND_CORNER	TR	Modify>Modify
Split Element	ID_SPLIT	SL	Modify>Modify
Array	ID_EDIT_CREATE_PATTERN	AR	Modify>Modify
Trim/Extend Single Element	ID_TRIM_EXTEND_SINGLE		Modify>Modify
Split with Gap	ID_SPLIT_WITH_GAP		Modify>Modify
Scale	ID_EDIT_SCALE	RE	Modify>Modify
Trim/Extend Multiple Elements	ID_TRIM_EXTEND_MULTIPLE		Modify>Modify
Unpin	ID_UNLOCK_ELEMENTS	UP	Modify>Modify
Pin	ID_LOCK_ELEMENTS	PN	Modify>Modify
Delete	ID_BUTTON_DELETE	DE	Modify>Modify
Measure:Measure Between Two References	ID_MEASURE_LINE		Modify>Measure; Quick Access Toolbar
Measure:Measure Along An Element	ID_MEASURE_PICK_LINES		Modify>Measure; Quick Access Toolbar
Create Similar	ID_EDIT_CREATE_SIMILAR	CS	Modify>Create
Load into Project; Model Group:Load as Group into Open Proj	ID_LOAD_INTO_PROJECTS		Family Editor>Family Editor; Architecture>Model; Structure>Model
Load into Project and Close	ID_LOAD_INTO_PROJECTS_CLOSE		Family Editor>Family Editor
Filled Region; Filled Region	ID_OBJECTS_FILLED_REGION		Create>Detail; Annotate>Detail
Label	ID_OBJECTS_TAG_NOTE		Create>Text
Revision Schedule	ID_VIEW_NEW_REVISION_SCHEDULE		View>Create
Top Chord; Top Chord	ID_TRUSS_TOP_CHORD_CURVE		Create>Detail; Contextual Tabs>Draw
Web	ID_TRUSS_WEB_CURVE		Create>Detail; Contextual Tabs>Draw
Bottom Chord; Bottom Chord	ID_TRUSS_BOTTOM_CHORD_CURVE		Create>Detail; Contextual Tabs>Draw
Rebar Line	ID_OBJECTS_REBAR_CURVE		Create>Draw; Modify>Draw
Major Segment	ID_MAJOR_SEGMENT		Create>Draw; Modify>Draw
Allowable Bar Types	ID_REBAR_SHAPE_ALLOWABLE_BAR_TYPES		Create>Rebar Types
Multi-planar	ID_TURN_ON_MULTI_PLANAR_SHAPE		Family Editor>Family Editor
Shape Status	ID_SHAPE_STATUS		Family Editor>Family Editor
Load into Project	ID_LOAD_INTO_PROJECTS_REBAR_SHAPE		Family Editor>Family Editor
Load into Project	ID_LOAD_INTO_PROJECTS_CLOSE_REBAR_SHAPE		Family Editor>Family Editor
Place Mass	ID_OBJECTS_MASS		Create>Model; Massing & Site>Conceptual Mass
Draw on Face	Dialog_Essentials_GenhostCreate:Control_Essentials_DrawOnFaces		Create>Draw; Modify>Draw; Contextual Tabs>Placement
Draw on Work Plane	Dialog_Essentials_GenhostCreate:Control_Essentials_DrawOnWorkplane		Create>Draw; Modify>Draw; Contextual Tabs>Placement
Level	ID_OBJECTS_LEVEL	LL	Create>Datum; Architecture>Datum; Structure>Datum
Additional Settings:Sun Settings	ID_SETTINGS_SUNANDSHADOWSSETTINGS	SU	Manage>Settings
Location	ID_GEO_MANAGE_LOCATIONS		Manage>Project Location
Split Face	ID_SPLIT_FACE_IN_NEW_FAMILIES	SF	Modify>Geometry
Repeat; Repeat Component	ID_REPEAT_COMPONENT		Modify>Modify
Wall; Wall:Wall: Architectural	ID_OBJECTS_WALL	WA	Architecture>Build; Structure>Structure
Wall:Wall: Structural	ID_OBJECTS_STRUCTURAL_WALL		Architecture>Build; Structure>Structure
Wall:Wall by Face	ID_WALL_PICK_FACES		Architecture>Build; Massing & Site>Model by Face; Contextual Tabs>Draw
Wall:Wall: Sweep	ID_OBJECTS_CORNICE		Architecture>Build; Structure>Structure
Wall:Wall: Reveal	ID_OBJECTS_REVEAL		Architecture>Build; Structure>Structure
Door	ID_OBJECTS_DOOR	DR	Architecture>Build
Window	ID_OBJECTS_WINDOW	WN	Architecture>Build
Component:Model In-Place	ID_INPLACE_COMPONENT		Architecture>Build; Structure>Model; Systems>Model
Column; Structural Column	ID_OBJECTS_STRUCTURAL_COLUMN	CL	Architecture>Build; Structure>Structure
Column:Column: Architectural	ID_OBJECTS_COLUMN		Architecture>Build
Roof; Roof by Footprint	ID_ROOF_FOOTPRINT		Architecture>Build
Roof:Roof by Extrusion	ID_ROOF_EXTRUSION		Architecture>Build
Roof:Roof by Face	ID_ROOF_PICK_FACES		Architecture>Build; Massing & Site>Model by Face
Roof:Roof: Soffit	ID_CREATE_SOFFIT_TB		Architecture>Build
Roof:Roof: Fascia	ID_CREATE_FASCIA_TB		Architecture>Build

Roof:Roof: Gutter	ID_CREATE_GUTTER_TB		Architecture>Build
Ceiling; Automatic Ceiling	ID_OBJECTS_CEILING		Architecture>Build; Contextual Tabs>Ceiling
Floor; Floor:Floor: Architectural	ID_OBJECTS_FLOOR		Architecture>Build; Structure>Structure
Floor:Floor: Structural	ID_OBJECTS_SLAB	SB	Architecture>Build; Structure>Structure
Floor:Floor by Face	ID_FLOOR_PICK_FACES		Architecture>Build; Massing & Site>Model by Face
Floor:Floor: Slab Edge; Slab:Floor: Slab Edge	ID_CREATE_SLAB_EDGE_TB		Architecture>Build; Structure>Structure; Structure>Foundation
Curtain System by Face	ID_CURTA_SYSTEM_PICK_FACES		Architecture>Build; Massing & Site>Model by Face
Curtain Grid	ID_OBJECTS_CW_GRID		Architecture>Build
Curtain Wall Mullion	ID_OBJECTS_MULLION		Architecture>Build
Railing	ID_OBJECTS_RAILING		Architecture>Circulation
Railing:Place on Host	ID_OBJECTS_RAILING_ON_HOST		Architecture>Circulation
Ramp	ID_OBJECTS_RAMP		Architecture>Circulation
Stair	ID_OBJECTS_STAIRS		Architecture>Circulation
Stair:Stair by Sketch	ID_OBJECTS_STAIRS_LEGACY		Architecture>Circulation
Model Line	ID_OBJECTS_PROJECT_CURVE	LI	Architecture>Model; Structure>Model
Room	ID_OBJECTS_ROOM	RM	Architecture>Room & Area
Room Separator	ID_OBJECTS_AREA_SEPARATION		Architecture>Room & Area
Tag Room; Tag Room; Room Tag	ID_OBJECTS_ROOM_TAG	RT	Architecture>Room & Area; Annotate>Tag
Tag Room:Tag All Not Tagged; Tag Area:Tag All Not Tagged	ID_BUTTON_TAG_ALL		Architecture>Room & Area; Annotate>Tag
Area	ID_OBJECTS_AREA		Architecture>Room & Area
Area Boundary	ID_OBJECTS_AREAScheme_BOUNDARY		Architecture>Room & Area
Tag Area; Tag Area; Area Tag	ID_OBJECTS_AREA_TAG		Architecture>Room & Area; Annotate>Tag
Color Schemes	ID_SETTINGS_COLORFILLSCHEMES		Architecture>Room & Area; Analyze>Spaces & Zones
Area and Volume Computations	ID_SETTING_AREACALCULATIONS		Architecture>Room & Area; Analyze>Spaces & Zones
Opening by Face	ID_CREATE_OPENING_BY_FACE_TB		Architecture>Opening; Structure>Opening
Shaft Opening	ID_CREATE_SHAFT_OPENING_TB		Architecture>Opening; Structure>Opening
Wall Opening	ID_CREATE_WALL_OPENING_TB		Architecture>Opening; Structure>Opening
Vertical Opening	ID_CREATE_VERTICAL_OPENING_TB		Architecture>Opening; Structure>Opening
Dormer Opening	ID_CREATE_DORMER_OPENING_TB		Architecture>Opening; Structure>Opening
Grid	ID_OBJECTS_GRID	GR	Architecture>Datum; Structure>Datum
Structural Framing: Beam	ID_OBJECTS_BEAM	BM	Structure>Structure
Structural Trusses	ID_OBJECTS_TRUSS		Structure>Structure
Structural Framing: Brace	ID_OBJECTS_BRACE	BR	Structure>Structure
Structural Beam System; Automatic Beam System	ID_OBJECTS_JOIST_SYSTEM	BS	Structure>Structure; Contextual Tabs>Beam System
Structural Foundation: Isolated	ID_OBJECTS_ISOLATED_FOOTING		Structure>Foundation
Structural Foundation: Wall	ID_OBJECTS_CONTINUOUS_FOOTING	FT	Structure>Foundation
Slab; Structural Foundation: Slab	ID_OBJECTS_FOOTING_SLAB		Structure>Foundation
Structural Rebar	ID_REBAR_PLACE		Structure>Reinforcement; Contextual Tabs>Reinforcement
Structural Area Reinforcement	ID_REBAR_SYSTEM_SKETCH		Structure>Reinforcement
Structural Path Reinforcement	ID_PATH_REIN_SKETCH		Structure>Reinforcement
Structural Fabric Area	ID_FABRIC_DISTR_SYSTEM_SKETCH		Structure>Reinforcement
Single Fabric Sheet Placement	ID_FABRIC_SINGLE_PLACEMENT		Structure>Reinforcement; Contextual Tabs>Reinforcement
Edit Rebar Cover	ID_CONCRETE_COVER		Structure>Reinforcement
Rebar Cover Settings	ID_REBAR_COVER_SETTINGS		Structure>Reinforcement
Reinforcement Settings	ID_REBAR_ABBREVIATION		Structure>Reinforcement
Reinforcement Numbers	ID_NUMBERING_REINF_PARTITIONS	RN	Structure>Reinforcement
Duct	ID_RBS_MECHANICAL_DUCT	DT	Systems>HVAC
Duct Placeholder	ID_DUCT_1LINE_PATH		Systems>HVAC
Duct Fitting	ID_RBS_MECHANICAL_FITTING	DF	Systems>HVAC
Duct Accessory	ID_RBS_MECHANICAL_ACCESSORY	DA	Systems>HVAC
Convert to Flex Duct	ID_RBS_MECHANICAL_CONVERTTOFLEX	CV	Systems>HVAC
Flex Duct	ID_RBS_MECHANICAL_FLEX	FD	Systems>HVAC
Air Terminal	ID_RBS_MECHANICAL_DIFFUSER	AT	Systems>HVAC
Mechanical Equipment	ID_RBS_MECHANICAL_EQUIPMENT	ME	Systems>Mechanical

Pipe	ID_RBS_PIPE_PIPE	PI	Systems>Plumbing & Piping
Pipe Placeholder	ID_PIPE_1LINE_PATH		Systems>Plumbing & Piping
Parallel Pipes	ID_PARALLEL_PIPES		Systems>Plumbing & Piping
Pipe Fitting	ID_RBS_PIPE_FITTING	PF	Systems>Plumbing & Piping
Pipe Accessory	ID_RBS_PIPE_ACCESSORY	PA	Systems>Plumbing & Piping
Flex Pipe	ID_RBS_PIPE_FLEX	FP	Systems>Plumbing & Piping
Plumbing Fixture	ID_RBS_PLUMBING_FIXTURE	PX	Systems>Plumbing & Piping
Sprinkler	ID_RBS_SPRINKLER	SK	Systems>Plumbing & Piping
Arc Wire	ID_RBS_ELECTRICAL_WIRE	EW	Systems>Electrical
Spline Wire	ID_RBS_ELECTRICAL_WIRE_SPLINE		Systems>Electrical
Chamfered Wire	ID_RBS_ELECTRICAL_WIRE_CHAMFER		Systems>Electrical
Cable Tray	ID_RBS_CABLE_TRAY	CT	Systems>Electrical
Conduit	ID_RBS_CONDUIT	CN	Systems>Electrical
Parallel Conduits	ID_PARALLEL_CONDUIT		Systems>Electrical
Cable Tray Fitting	ID_RBS_CABLETRAY_FITTING	TF	Systems>Electrical
Conduit Fitting	ID_RBS_CONDUIT_FITTING	NF	Systems>Electrical
Electrical Equipment	ID_RBS_ELECTRICAL_EQUIPMENT	EE	Systems>Electrical
Electrical Fixture	ID_RBS_ELECTRICAL_DEVICE		Systems>Electrical
Communication	ID_RBS_ELECTRICAL_COMMUNICATION_DEVICE		Systems>Electrical
Data	ID_RBS_ELECTRICAL_DATA_DEVICE		Systems>Electrical
Fire Alarm	ID_RBS_ELECTRICAL_FIREALARM_DEVICE		Systems>Electrical
Lighting	ID_RBS_ELECTRICAL_LIGHTING_DEVICE		Systems>Electrical
Nurse Call	ID_RBS_ELECTRICAL_NURSECALL_DEVICE		Systems>Electrical
Security	ID_RBS_ELECTRICAL_SECURITY_DEVICE		Systems>Electrical
Telephone	ID_RBS_ELECTRICAL_TELEPHONE_DEVICE		Systems>Electrical
Lighting Fixture	ID_RBS_LIGHTING_FIXTURE	LF	Systems>Electrical
Linear Dimension	ID_ANNOTATIONS_DIMENSION_LINEAR		Annotate>Dimension; Modify>Measure; Contextual Tabs>Dimension
Spot Elevation; Spot Elevation	ID_SPOT_ELEVATION	EL	Annotate>Dimension; Modify>Measure; Contextual Tabs>Dimension
Spot Coordinate; Spot Coordinate	ID_SPOT_COORDINATE		Annotate>Dimension; Modify>Measure; Contextual Tabs>Dimension
Spot Slope; Spot Slope	ID_SPOT_SLOPE		Annotate>Dimension; Modify>Measure; Contextual Tabs>Dimension
Spot Elevation Types	ID_SETTINGS_SPOT_ELEVATION		Annotate>Dimension
Spot Coordinate Types	ID_SETTINGS_SPOT_COORDINATE		Annotate>Dimension
Spot Slope Types	ID_SETTINGS_SPOT_SLOPE		Annotate>Dimension
Detail Line	ID_OBJECTS_DETAIL_CURVES	DL	Annotate>Detail
Repeating Detail Component	ID_OBJECTS_REPEATING_DETAIL		Annotate>Detail
Legend Component	ID_OBJECTS_LEGEND_COMPONENT		Annotate>Detail
Revision Cloud	ID_OBJECTS_CLOUD		Annotate>Detail
Insulation	ID_OBJECTS_INSULATION		Annotate>Detail
Tag by Category; Tag by Category	ID_BUTTON_TAG	TG	Annotate>Tag; Quick Access Toolbar
Beam Annotations	ID_BEAM_ANNOTATION_PLACEMENT		Annotate>Tag
Multi-Category Tag	ID_TAG_MULTI		Annotate>Tag
Material Tag	ID_TAG_MATERIAL		Annotate>Tag
Space Tag	ID_OBJECTS_MEP_SPACE_TAG		Annotate>Tag; Analyze>Spaces & Zones
View Reference	ID_NEW_REFERENCE_VIEWER		Annotate>Tag; View>Sheet Composition
Stair Tread/Riser Number	ID_STAIRS_TRISER_NUMBER		Annotate>Tag
Aligned Multi-Rebar Annotation	ID_MULTI_REFERENCE_ANNOTATION_ALIGNED		Annotate>Tag
Linear Multi-Rebar Annotation	ID_MULTI_REFERENCE_ANNOTATION_LINEAR		Annotate>Tag
Element Keynote	ID_KEYNOTE_ELEMENT		Annotate>Tag
Material Keynote	ID_KEYNOTE_MATERIAL		Annotate>Tag
User Keynote	ID_KEYNOTE_USER		Annotate>Tag
Loaded Tags And Symbols	ID_SETTINGS_TAGS		Annotate>Tag
Duct Legend	ID_RBS_MECHANICAL_COLOR_FILL		Annotate>Color Fill; Analyze>Color Fill
Pipe Legend	ID_RBS_PIPING_COLOR_FILL		Annotate>Color Fill; Analyze>Color Fill
Color Fill Legend	ID_OBJECTS_ROOM_FILL		Annotate>Color Fill; Analyze>Color Fill

Span Direction Symbol	ID_OBJECTS_SPAN_DIR_SYM		Annotate>Symbol
Beam System Symbol	ID_OBJECTS_BEAM_SYSTEM_TAG		Annotate>Symbol
Stair Path	ID_OBJECTS_STAIRS_PATH		Annotate>Symbol
Area Reinforcement Symbol	ID_OBJECTS_REBAR_SYSTEM_SPAN_SYM		Annotate>Symbol
Path Reinforcement Symbol	ID_OBJECTS_PATH_REIN_SPAN_SYM		Annotate>Symbol
Fabric Reinforcement Symbol	ID_FABRIC_SYSTEM_PLACE_SPANSYMBOL		Annotate>Symbol
Loads	ID_OBJECT_LOADS	LD	Analyze>Loads
Load Cases	ID_STRUCTURAL_SETTINGS_LOAD_CASES		Analyze>Loads
Load Combinations	ID_STRUCTURAL_SETTINGS_LOAD_COMB		Analyze>Loads
Boundary Conditions	ID_OBJECT_BC		Analyze>Boundary Conditions
Adjust Analytical Model	ID_AM_EDIT_MODE_START	AA	Analyze>Analytical Model Tools; Contextual Tabs>Analytical Model
Reset Analytical Model	ID_RESET_ANALYTICAL_MODEL	RA	Analyze>Analytical Model Tools
Check Member Supports	ID_COMMAND_CHECK_MEMBER_SUPPORTS		Analyze>Analytical Model Tools
Analytical Consistency Checks	ID_COMMAND_ANALYTICAL_CONSISTENCY_CHECKS		Analyze>Analytical Model Tools
Space	ID_OBJECTS_MEP_SPACE		Analyze>Spaces & Zones
Space Separator	ID_OBJECTS_MEP_SPACE_SEPARATION		Analyze>Spaces & Zones
Zone	ID_RBS_HVAC_ZONE		Analyze>Spaces & Zones
Heating and Cooling Loads	ID_RBS_HVAC_LOADS	LO	Analyze>Reports & Schedules
Panel Schedules	ID_RBS_VIEW_PANEL_SCHEDULE	PS	Analyze>Reports & Schedules
Duct Pressure Loss Report	ID_MEP_DUCT_PRESSURE_LOSS_REPORT		Analyze>Reports & Schedules
Pipe Pressure Loss Report	ID_MEP_PIPE_PRESSURE_LOSS_REPORT		Analyze>Reports & Schedules
Check Duct Systems	ID_RBS_CHECK_DUCT_SYSTEMS	DC	Analyze>Check Systems
Check Pipe Systems	ID_RBS_CHECK_PIPE_SYSTEMS	PC	Analyze>Check Systems
Check Circuits	ID_RBS_CHECK_CIRCUITS	EC	Analyze>Check Systems
Show Disconnects	ID_SHOWDISCONNECTS_BUTTON		Analyze>Check Systems
Use Conceptual Mass Mode	ID_ANALYZE_CONCEPTUAL_MODEL		Analyze>Energy Analysis
Use Building Element Mode	ID_ANALYZE_BUILDING_ELEMENTS		Analyze>Energy Analysis
Energy Settings	ID_CEA_VIEW_ENERGY_DATA		Analyze>Energy Analysis
Enable Energy Model	ID_ENABLE_ENERGY_ANALYSIS		Analyze>Energy Analysis
Run Energy Simulation	ID_CEA_LAUNCH_ANALYSIS		Analyze>Energy Analysis
Results & Compare	ID_CEA_LAUNCH_DASHBOARD		Analyze>Energy Analysis
Show Mass by View Settings	ID_SHOW_MASS_NO_OVERRIDE		Massing & Site>Conceptual Mass
Show Mass Form and Floors	ID_SHOW_MASS_STANDARD		Massing & Site>Conceptual Mass
Show Mass Surface Types	ID_SHOW_MASS_SURFACES		Massing & Site>Conceptual Mass
Show Mass Zones and Shades	ID_SHOW_MASS_ZONES		Massing & Site>Conceptual Mass
In-Place Mass	ID_INPLACE_MASS		Massing & Site>Conceptual Mass
Toposurface	ID_SITE_TOPO_SURFACE		Massing & Site>Model Site
Site Component	ID_SITE_COMPONENT		Massing & Site>Model Site
Parking Component	ID_SITE_PARKING_COMPONENT		Massing & Site>Model Site
Building Pad	ID_SITE_BUILDINGPAD		Massing & Site>Model Site
Split Surface	ID_SPLIT_SURFACE		Massing & Site>Modify Site
Merge Surfaces	ID_MERGE_SURFACE		Massing & Site>Modify Site
Subregion	ID_SITE_AREA		Massing & Site>Modify Site
Property Line	ID_SITE_PROPERTYLINE		Massing & Site>Modify Site
Graded Region	ID_SITE_GRADE		Massing & Site>Modify Site
Label Contours	ID_SITE_LABEL_CONTOURS		Massing & Site>Modify Site
Worksets	ID_SETTINGS_PARTITIONS		Collaborate>Manage Collaboration
Gray Inactive Worksets	ID_GRAY_INACTIVE_WORKSET_GRAPHICS		Collaborate>Manage Collaboration
Synchronize with Central:Synchronize and Modify Settings	ID_FILE_SAVE_TO_MASTER		Collaborate>Synchronize; Quick Access Toolbar
Synchronize with Central:Synchronize Now	ID_FILE_SAVE_TO_MASTER_SHORTCUT		Collaborate>Synchronize; Quick Access Toolbar
Reload Latest	ID_WORKSETS_RELOAD_LATEST	RL#RW	Collaborate>Synchronize
Relinquish All Mine	ID_RELINQUISH_ALL_MINE		Collaborate>Synchronize
Show History	ID_PARTITIONS_SHOW_HISTORY		Collaborate>Synchronize
Restore Backup	ID_FILE_BACKUPS		Collaborate>Synchronize

Editing Requests	ID_WORKSET_EDITING_REQUESTS	ER	Collaborate>Synchronize
Manage Connection to a Revit Server Accelerator	ID_MANAGE_CONNECTION_TO_A_REVIT_SERVER_ACCELERATOR		Collaborate>Synchronize
Copy/ Monitor:Use Current Project	ID_COPY_WATCH_CURRENT		Collaborate>Coordinate
Copy/ Monitor:Select Link	ID_COPY_WATCH_LINK		Collaborate>Coordinate
Coordination Review:Use Current Project	ID_RECONCILE_CURRENT		Collaborate>Coordinate
Coordination Review:Select Link	ID_RECONCILE_LINK		Collaborate>Coordinate
Coordination Settings	ID_COPY_SETTINGS		Collaborate>Coordinate; Contextual Tabs>Tools
Reconcile Hosting	ID_TOGGLE_HOST_BY_LINK_BROWSER		Collaborate>Coordinate; Contextual Tabs>Host
Interference Check:Run Interference Check	ID_INTERFERENCE_CHECK		Collaborate>Coordinate
Interference Check:Show Last Report	ID_INTERFERENCE_REPORT		Collaborate>Coordinate
View Templates:Apply Template Properties to Current View	ID_APPLY_VIEW_TEMPLATE		View>Graphics
View Templates>Create Template from Current View	ID_CREATE_VIEW_TEMPLATE		View>Graphics
View Templates:Manage View Templates	ID_SETTINGS_VIEWTEMPLATES		View>Graphics
Filters	ID_SETTINGS_FILTERS		View>Graphics
Show Hidden Lines by Element	ID_HIDE_ELEMENTS_EDITOR		View>Graphics
Remove Hidden Lines by Element	ID_UNHIDE_ELEMENTS_EDITOR		View>Graphics
Cut Profile	ID_EDIT_CUT_BOUNDARY		View>Graphics
Render	ID_PHOTO_RENDERING_VIEW	RR	View>Graphics; View Control Bar
Render in Cloud	ID_PHOTO_RENDER_IN_CLOUD	RC	View>Graphics; View Control Bar
Render Gallery	ID_PHOTO_RENDER_GALLERY	RG	View>Graphics; View Control Bar
Callout	ID_VIEW_NEW_CALLOUT		View>Create
Callout:Sketch	ID_VIEW_NEW_CALLOUT_SKETCH		View>Create
Drafting View	ID_VIEW_NEW_DRAFTING		View>Create
Scope Box	ID_VOLUME_OF_INTEREST		View>Create
Sheet; New Sheet	ID_VIEW_NEW_SHEET		View>Sheet Composition; Contextual Tabs>Create
Place View	ID_VIEW_PLACE_VIEW		View>Sheet Composition
Title Block	ID_OBJECTS_PLACE_TITLEBLOCK		View>Sheet Composition
Sheet Issues/Revisions; Additional Settings:Sheet Issues/Revisions	ID_SETTINGS_REVISIONS		View>Sheet Composition; Manage>Settings
Guide Grid	ID_CREATE_GUIDE_GRID		View>Sheet Composition
Matchline	ID_NEW_MATCHLINE		View>Sheet Composition
Viewports:Activate View; Activate View	ID_VIEWPORT_ACTIVATE		View>Sheet Composition; Contextual Tabs>Viewport; Context Menu
Viewports:Deactivate View	ID_VIEWPORT_ACTIVATE_BASE		View>Sheet Composition; Context Menu
Project Information	ID_SETTINGS_PROJECT_INFORMATION		Manage>Settings
Project Parameters	ID_SETTINGS_PROJECT_PARAMETERS		Manage>Settings
MEP Settings:Mechanical Settings	ID_RBS_MECHANICAL_SETTINGS	MS	Manage>Settings
MEP Settings:Electrical Settings	ID_RBS_ELECTRICAL_SETTINGS	ES	Manage>Settings
MEP Settings:Building/Space Type Settings	ID_RBS_BUILDINGSPLACE_TYPE_SETTINGS	BS	Manage>Settings
Additional Settings:Material Assets	ID_SETTINGS_RENDERING_APPEARANCE		Manage>Settings
Additional Settings:Halftone / Underlay	ID_SETTINGS_HALFTONE		Manage>Settings
Additional Settings:Callout Tags	ID_VIEWTAGSTYLES_CALLOUTTAGS		Manage>Settings
Additional Settings:Elevation Tags	ID_VIEWTAGSTYLES_ELEVATIONTAGS		Manage>Settings
Coordinates:Acquire Coordinates	ID_GEO_ACQUIRE_COORDINATES		Manage>Project Location
Coordinates:Publish Coordinates	ID_GEO_PUBLISH_COORDINATES		Manage>Project Location
Coordinates:Specify Coordinates at Point	ID_SPECIFY_SHARED_COORDINATES		Manage>Project Location
Coordinates:Report Shared Coordinates	ID_REPORT_SHARED_COORDINATES		Manage>Project Location
Position:Relocate Project	ID_RELOCATE_SHARED_COORDINATES		Manage>Project Location
Position:Rotate True North	ID_ROTATE_SHARED_COORDINATES		Manage>Project Location
Position:Mirror Project	ID_MIRROR_PROJECT		Manage>Project Location
Position:Rotate Project North	ID_ROTATE_PROJECT		Manage>Project Location
Design Options	ID_EDIT_DESIGNOPTIONS		Manage>Design Options
Add to Set	ID_EDIT_ADDTODESIGNOPTIONSET		Manage>Design Options
Pick to Edit	ID_EDIT_PICKS_OPTION		Manage>Design Options
Phases	ID_SETTINGS_PHASES		Manage>Phasing
Save Selection	ID_FILTERS_SELECTION_SAVE		Manage>Selection; Contextual Tabs>Selection

Load Selection	ID_RETRIEVE_FILTERS		Manage>Selection; Contextual Tabs>Selection
Edit Selection	ID_EDIT_SELECTIONS		Manage>Selection; Contextual Tabs>Selection
Join:Switch Join Order	ID_SWITCH_JOIN_ORDER_EDITOR		Modify>Geometry
Join/Unjoin Roof	ID_JOIN_ROOF		Modify>Geometry
Beam/Column Joins	ID_EDIT_BEAM_JOINS		Modify>Geometry
Wall Joins	ID_EDIT_WALL_JOINS		Modify>Geometry
Demolish	ID_EDIT_DEMOLISH		Modify>Geometry
Hide in View:Hide Elements	ID_VIEW_HIDE_ELEMENTS	EH	Modify>View
Hide in View:Hide Category	ID_VIEW_HIDE_CATEGORY	VH	Modify>View
Hide in View:Hide by Filter; Override Graphics in View:Override	ID_VIEW_GO_FILTER		Modify>View
Displace Elements	ID_DISPLACEMENT_CREATE		Modify>View
Override Graphics in View:Override by Element	ID_VIEW_OVERRIDE_ELEMENTS	EOD	Modify>View
Override Graphics in View:Override by Category	ID_VIEW_OVERRIDE_CATEGORY		Modify>View
Linework	ID_EDIT_LINEWORK	LW	Modify>View
Create Assembly	ID_CREATE_ASSEMBLY		Modify>Create
Create Parts	ID_CREATE_PARTS		Modify>Create
Finish Model	ID_END_INPLACE_FAMILY		In-Place Model>In-Place Editor
Cancel Model	ID_QUIT_INPLACE_FAMILY		In-Place Model>In-Place Editor
Finish Mass	ID_END_INPLACE_MASS		In-Place Mass>In-Place Editor
Cancel Mass	ID_QUIT_INPLACE_MASS		In-Place Mass>In-Place Editor
Slope Control Point	ID_RBS_TOGGLE_END_REFERENCE		Contextual Tabs>Slope; Contextual Tabs>Justify
Finish	ID_RBS_FINISH_JUSTIFY_SLOPE_EDITMODE		Contextual Tabs>Slope Editor; Contextual Tabs>Justify Editor
Cancel	ID_RBS_CANCEL_JUSTIFY_SLOPE_EDITMODE		Contextual Tabs>Slope Editor; Contextual Tabs>Justify Editor
Cancel Edit Mode	ID_CANCEL_SKETCH		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_SKETCH		Contextual Tabs>Mode
Boundary	ID_BUTTON_STAIRS_LANDING_SKETCH		Contextual Tabs>Draw
Stairs Path; Stair Path	ID_BUTTON_STAIRS_PATH		Contextual Tabs>Draw
Cancel Edit Mode	ID_QUIT_SKETCH_PROFILE		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_SKETCH_PROFILE		Contextual Tabs>Mode
Axis Line	ID_OBJECTS_AXIS		Contextual Tabs>Draw
System Inspector	ID_RBS_SYSTEM_INSPECTOR_INSPECT		Contextual Tabs>System Inspector
Finish	ID_RBS_SYSTEM_INSPECTOR_FINISH		Contextual Tabs>System Inspector
Cancel	ID_RBS_SYSTEM_INSPECTOR_CANCEL		Contextual Tabs>System Inspector
Add to Displacement	ID_DISPLACEMENT_ADD_ELEMENT		Contextual Tabs>Edit Displacement Set
Remove from Displacement	ID_DISPLACEMENT_REMOVE_ELEMENT		Contextual Tabs>Edit Displacement Set
Finish	ID_DISPLACEMENT_FINISH_EDIT		Contextual Tabs>Edit Displacement Set
Cancel	ID_DISPLACEMENT_CANCEL_EDIT		Contextual Tabs>Edit Displacement Set
Edit Base	ID_EDIT_BLEND_BASE		Contextual Tabs>Mode
Edit Vertices	ID_EDIT_VERTEX_CONNECTIONS		Contextual Tabs>Mode; Contextual Tabs>Sweep; Contextual Tabs>Swept Blend
Pick New Host; Pick New Host	ID_RAILING_SET_HOST		Contextual Tabs>Tools
Edit Joins	ID_RAILING_EDIT_JOINS		Contextual Tabs>Tools
Preview	ID_RAILING_EDIT_MODE_TOGGLE_PREVIEW		Contextual Tabs>Options
Cancel Edit Mode	ID_RAILPATH_EDITMODE_QUIT		Contextual Tabs>Mode
Finish Edit Mode	ID_RAILPATH_EDITMODE_FINISH		Contextual Tabs>Mode
Edit Rail Joins	ID_EDIT_CONTINUOUS_RAIL_JOINS		Contextual Tabs>Joins
Cancel Edit Mode	ID_QUIT_SWEEP		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_SWEEP		Contextual Tabs>Mode
Sketch Path	ID_SKETCH_2D_PATH		Contextual Tabs>Sweep; Contextual Tabs>Swept Blend
Pick Path	ID_PICK_PATH		Contextual Tabs>Sweep; Contextual Tabs>Swept Blend
Select Profile	ID_SWEEP_PROFILE		Contextual Tabs>Sweep
Edit Profile; Edit Profile	Dialog_Essentials_ProfileFamTypeDbar:Control_Essentials_EditSketch		Contextual Tabs>Sweep; Contextual Tabs>Swept Blend; Contextual Tabs>Profile
Load Profile	Dialog_Essentials_ProfileFamTypeDbar:Control_Essentials_LoadFamily		Contextual Tabs>Sweep; Contextual Tabs>Swept Blend; Contextual Tabs>Profile
Cancel Edit Mode	ID_QUIT_PICK_BOUNDARY		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_PICK_BOUNDARY		Contextual Tabs>Mode

Pick Roof/ Wall Edges	ID_PICK_DORMER_BOUNDARY	Contextual Tabs>Pick
Analytical Wall Adjustment	ID_ADJUST_ANALYTICAL_WALL	Contextual Tabs>Edit Analytical Model
Include/Exclude Openings	ID_INCLUDE_EXCLUDE_OPENING_FROM_ANALYTICAL_SURFACE	Contextual Tabs>Edit Analytical Model
Create Analytical Link	ID_CREATE_ANALYTICAL_LINK	Contextual Tabs>Edit Analytical Model
Finish	ID_AM_EDIT_MODE_FINISH	Contextual Tabs>Edit Analytical Model
Cancel	ID_AM_EDIT_MODE_CANCEL	Contextual Tabs>Edit Analytical Model
Add to Group	ID_ADD_LIGHT_TO_GROUP	Contextual Tabs>Light Group
Remove from Group	ID_REMOVE_LIGHT_FROM_GROUP	Contextual Tabs>Light Group
Finish	ID_FINISH_LIGHT_GROUP_EDIT	Contextual Tabs>Light Group
Cancel	ID_CANCEL_LIGHT_GROUP_EDIT	Contextual Tabs>Light Group
Cancel Edit Mode	ID_QUIT_SWEEP_BLEND	Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_SWEEP_BLEND	Contextual Tabs>Mode
Select Profile 1	ID_SKETCH_PROFILE_1	Contextual Tabs>Sweep Blend
Select Profile 2	ID_SKETCH_PROFILE_2	Contextual Tabs>Sweep Blend
Major Direction	ID_REBAR_SYSTEM_PICK_DIRSPAN_EDGE	Contextual Tabs>Draw
Cancel Edit Mode	ID_MERGED_PART_CANCEL_EDIT	Contextual Tabs>Mode
Finish Edit Mode	ID_MERGED_PART_FINISH_EDIT	Contextual Tabs>Mode
Add	ID_MERGED_PART_ADD	Contextual Tabs>Merged Parts
Remove	ID_MERGED_PART_REMOVE	Contextual Tabs>Merged Parts
Edit Path	ID_EDIT_CONTINUOUS_RAIL_PATH	Contextual Tabs>Tools
Reset Rail	ID_RESET_CONTINUOUS_RAIL	Contextual Tabs>Tools; Contextual Tabs>Continuous Rail
Symbolic Line	ID_SKETCH_SHAFTOPENING_SYMBOL	Contextual Tabs>Draw
Add to Selection	ID_EDITSFILTER_ADD_TO_FILTER	Contextual Tabs>Edit Selection
Remove from Selection	ID_EDITSFILTER_REMOVE_FROM_FILTER	Contextual Tabs>Edit Selection
Finish Selection	ID_FINISH_SFILTER_EDIT_MODE	Contextual Tabs>Selection Mode
Cancel Selection	ID_CANCEL_SFILTER_EDIT_MODE	Contextual Tabs>Selection Mode
Slope Arrow	ID_SKETCH_DEFINE_SLOPE	Contextual Tabs>Draw
Set Template Options	ID_RBS_PANELSCHEDULE_FORMAT_TEMPLATE	Contextual Tabs>Template
Remove Parameter	ID_PANELSCHEDULE_PARAM_REMOVE	Contextual Tabs>Parameters
Format Unit	ID_PANELSCHEDULE_PARAM_FORMATUNITS	Contextual Tabs>Parameters
Calculated Value	ID_PANELSCHEDULE_PARAM_CALCULATE	Contextual Tabs>Parameters
Combine Parameters	ID_PANELSCHEDULE_PARAM_COMBINE	Contextual Tabs>Parameters
Freeze Rows and Columns	ID_RBS_PANELSCHEDULE_FREEZE_COLANDROW	Contextual Tabs>Columns and Rows
Insert Column:Left of Selected	ID_PANELSCHEDULE_COLUMN_INSERT_LEFT	Contextual Tabs>Columns and Rows
Insert Column:Right of Selected	ID_PANELSCHEDULE_COLUMN_INSERT_RIGHT	Contextual Tabs>Columns and Rows
Delete Column	ID_PANELSCHEDULE_COLUMN_DELETE	Contextual Tabs>Columns and Rows
Resize Column	ID_PANELSCHEDULE_COLUMN_RESIZE	Contextual Tabs>Columns and Rows
Insert Row:Above Selected	ID_PANELSCHEDULE_ROW_INSERT_ABOVE	Contextual Tabs>Columns and Rows
Insert Row:Below Selected	ID_PANELSCHEDULE_ROW_INSERT_BELOW	Contextual Tabs>Columns and Rows
Delete Row	ID_PANELSCHEDULE_ROW_DELETE	Contextual Tabs>Columns and Rows
Resize Row	ID_PANELSCHEDULE_ROW_RESIZE	Contextual Tabs>Columns and Rows
Merge/ Unmerge	ID_PANELSCHEDULE_CELL_MERGE_UNMERGE	Contextual Tabs>Cells
Insert Graphic	ID_PANELSCHEDULE_CELL_INSERT_GRAPHIC	Contextual Tabs>Cells
Edit Borders	ID_PANELSCHEDULE_CELL_EDIT_BORDER	Contextual Tabs>Cells
Edit Shading	ID_PANELSCHEDULE_CELL_EDIT_SHADING	Contextual Tabs>Cells
Edit Font	ID_PANELSCHEDULE_TEXT_EDIT_FONT	Contextual Tabs>Text
Horizontally Align:Left	ID_PANELSCHEDULE_TEXT_HORIZONTAL_ALIGN_LEFT	Contextual Tabs>Text
Horizontally Align:Center	ID_PANELSCHEDULE_TEXT_HORIZONTAL_ALIGN_CENTER	Contextual Tabs>Text
Horizontally Align:Right	ID_PANELSCHEDULE_TEXT_HORIZONTAL_ALIGN_RIGHT	Contextual Tabs>Text
Vertically Align:Top	ID_PANELSCHEDULE_TEXT_VERTICAL_ALIGN_TOP	Contextual Tabs>Text
Vertically Align:Middle	ID_PANELSCHEDULE_TEXT_VERTICAL_ALIGN_MIDDLE	Contextual Tabs>Text
Vertically Align:Bottom	ID_PANELSCHEDULE_TEXT_VERTICAL_ALIGN_BOTTOM	Contextual Tabs>Text
Finish Template	ID_RBS_PANELSCHEDULE_TEMPLATEVIEW_FINISH	Contextual Tabs>Template Editor
Cancel Template	ID_RBS_PANELSCHEDULE_TEMPLATEVIEW_CANCEL	Contextual Tabs>Template Editor

Add to System	ID_RBS_SYSTEM_GROUP_EDIT_ADD_TO_GROUP	Contextual Tabs>Edit Piping System; Contextual Tabs>Edit Switch System; Contextual Tabs>Edit Duct
Remove from System	ID_RBS_SYSTEM_GROUP_EDIT_REMOVE_FROM_GROUP	Contextual Tabs>Edit Piping System; Contextual Tabs>Edit Switch System; Contextual Tabs>Edit Duct
Select Equipment	ID_RBS_SYSTEM_GROUP_EDIT_BASE_OBJECT_SELECT	Contextual Tabs>Edit Piping System; Contextual Tabs>Edit Duct System
Finish Editing System; Finish Editing Circuit	ID_RBS_FINISH_SYSTEM_GROUP_EDIT_MODE	Contextual Tabs>Mode
Cancel Editing System; Cancel Editing Circuit	ID_RBS_CANCEL_SYSTEM_GROUP_EDIT_MODE	Contextual Tabs>Mode
Cancel Edit Mode	ID_STAIRSEEDITMODE_QUIT	Contextual Tabs>Mode
Finish Edit Mode	ID_STAIRSEEDITMODE_FINISH	Contextual Tabs>Mode
Run	ID_STAIRS_RUN	Contextual Tabs>Components
Landing	ID_STAIRS_LANDING	Contextual Tabs>Components
Support	ID_STAIRS_SUPPORT	Contextual Tabs>Components
Convert to sketch-based	ID_STAIRS_CONVERT_TO_CUSTOM	Contextual Tabs>Tools
Edit Sketch	ID_EDIT_SKETCH	Contextual Tabs>Tools
Flip	ID_FLIP_STAIRS_DIRECTION	Contextual Tabs>Tools
Railing	ID_SET_RAILINGS_TYPE	Contextual Tabs>Tools
Filter	ID_BTN_FILTER_SELECTION	Contextual Tabs>Edit Pasted; Contextual Tabs>Selection
Select All	ID_SELECT_ALL_PASTED	Contextual Tabs>Edit Pasted
Finalize Selected	ID_FINALIZE_SELECTED_ELEMENTS	Contextual Tabs>Edit Pasted
Finish	ID_FINISH_PASTE_EDIT_MODE	Contextual Tabs>Edit Pasted
Cancel	ID_QUIT_PASTE_EDIT_MODE	Contextual Tabs>Edit Pasted
Cancel Edit Mode	ID_QUIT_PICK_PATH	Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_PICK_PATH	Contextual Tabs>Mode
Pick 3D Edges	ID_PICK_EDGES	Contextual Tabs>Pick
Beam Direction	ID_PICK_DIRSPAN_EDGE	Contextual Tabs>Draw
Reset Beam System	ID_RESET_JOIST_SYSTEM	Contextual Tabs>Adjust
Span Direction	ID_FLOOR_PICK_DISPAN_EDGE	Contextual Tabs>Draw
Finish Edit Mode	ID_FINISH_PROOF	Contextual Tabs>Mode
Slope Arrow	ID_SKETCH_DEFINE_ROOF_SLOPE	Contextual Tabs>Draw
Align Eaves	ID_SKETCH_ALIGN_EAVES	Contextual Tabs>Tools
Adjust Height	Dialog_Essentials_AdjustHeightOrOverhang:Control_Essentials_RadioHei	Contextual Tabs>Tools
Adjust Overhang	Dialog_Essentials_AdjustHeightOrOverhang:Control_Essentials_RadioOve	Contextual Tabs>Tools
Move Connector	ID_RBS_DRAG_SURFACE_CONNECTOR	Contextual Tabs>Move Connector
Finish Connection	ID_RBS_FINISH_SURFACE_CONNECTOR_EDIT_MODE	Contextual Tabs>Surface Connection
Cancel Connection	ID_RBS_CANCEL_SURFACE_CONNECTOR_EDIT_MODE	Contextual Tabs>Surface Connection
Stop	ID_IMAGE_RAYTRACE_STOP	Contextual Tabs>Interactive Ray Trace
Save	ID_IMAGE_RAYTRACE_SAVE	Contextual Tabs>Interactive Ray Trace
Close	ID_IMAGE_RAYTRACE_CANCEL	Contextual Tabs>Interactive Ray Trace
Edit Top	ID_EDIT_BLEND_TOP	Contextual Tabs>Mode
Multi-planar	ID_TURN_ON_MULTI_PLANAR_REBAR	Contextual Tabs>Reinforcement
Top Chord	ID_TRUSS_TOP_CHORD_REFERENCE	Contextual Tabs>Draw
Bottom Chord	ID_TRUSS_BOTTOM_CHORD_REFERENCE	Contextual Tabs>Draw
Edit Layout	ID_RBS_LAYOUTPATH_EDIT	Contextual Tabs>Modify Layout
Solutions	ID_RBS_LAYOUTPATH_SOLUTIONS	Contextual Tabs>Modify Layout
Add to System	ID_RBS_LAYOUTPATH_ADD	Contextual Tabs>Modify Layout
Remove from System	ID_RBS_LAYOUTPATH_REMOVE	Contextual Tabs>Modify Layout
Place Base	ID_RBS_LAYOUTPATH_BASE	Contextual Tabs>Modify Layout
Remove Base	ID_RBS_LAYOUTPATH_BASE_REMOVE	Contextual Tabs>Modify Layout
Modify Base	ID_RBS_LAYOUTPATH_BASE_MODIFY	Contextual Tabs>Modify Layout
Finish Layout	ID_RBS_LAYOUTPATH_FINISH	Contextual Tabs>Generate Layout
Cancel Layout	ID_RBS_LAYOUTPATH_CANCEL	Contextual Tabs>Generate Layout
Boundary	ID_BUTTON_STAIRS_RUN_BOUNDARY	Contextual Tabs>Draw
Riser	ID_BUTTON_STAIRS_RISER	Contextual Tabs>Draw
Alignment Line	ID_RBS_PICKALIGNMENT_LINE	Contextual Tabs>Justify
Alignment Top Left	ID_JUSTIFY_TOP_LEFT	Contextual Tabs>Justify
Alignment Middle Left	ID_JUSTIFY_MIDDLE_LEFT	Contextual Tabs>Justify

Alignment Bottom Left	ID_JUSTIFY_BOTTOM_LEFT		Contextual Tabs>Justify
Alignment Top Center	ID_JUSTIFY_TOP_CENTER		Contextual Tabs>Justify
Alignment Middle Center	ID_JUSTIFY_MIDDLE_CENTER		Contextual Tabs>Justify
Alignment Bottom Center	ID_JUSTIFY_BOTTOM_CENTER		Contextual Tabs>Justify
Alignment Top Right	ID_JUSTIFY_TOP_RIGHT		Contextual Tabs>Justify
Alignment Middle Right	ID_JUSTIFY_MIDDLE_RIGHT		Contextual Tabs>Justify
Alignment Bottom Right	ID_JUSTIFY_BOTTOM_RIGHT		Contextual Tabs>Justify
Select Switch	ID_RBS_SWITCH_SYSTEM_EDIT_SWITCH_SELECT		Contextual Tabs>Edit Switch System
Cancel Edit Mode	ID_CANCEL_DPART_EDIT		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_DPART_EDIT		Contextual Tabs>Mode
Edit Sketch	ID_SKETCH_DPART_EDIT		Contextual Tabs>Draw
Intersecting References	ID_DIVIDED_VOLUME_INTRST_LIST		Contextual Tabs>References
Add	ID_ADD_ELEMENT_TO_DIVISION		Contextual Tabs>Divided Parts
Remove	ID_REMOVE_ELEMENT_FROM_DIVISION		Contextual Tabs>Divided Parts
Reference Point	ID_PLACE_REF_POINT		Contextual Tabs>Tools
Add Space	ID_RBS_ZONE_ADD_SPACE		Contextual Tabs>Mode
Remove Space	ID_RBS_ZONE_REMOVE_SPACE		Contextual Tabs>Mode
Finish Editing Zone	ID_RBS_FINISH_ZONE_EDIT_MODE		Contextual Tabs>Edit Zone
Cancel Editing Zone	ID_RBS_CANCEL_ZONE_EDIT_MODE		Contextual Tabs>Edit Zone
Add to Group	ID_EDITGROUP_ADD_TO_GROUP	AP	Contextual Tabs>Edit Group
Remove from Group	ID_EDITGROUP_REMOVE_FROM_GROUP	RG	Contextual Tabs>Edit Group
Attach Detail Group	ID_EDITGROUP_ATTACH_TO_GROUP	AD	Contextual Tabs>Edit Group
Finish	ID_FINISH_GROUP_EDIT_MODE	FG	Contextual Tabs>Edit Group
Cancel	ID_CANCEL_GROUP_EDIT_MODE	CG	Contextual Tabs>Edit Group
Cancel Surface	ID_CANCEL_SURFACE		Contextual Tabs>Surface
Finish Surface	ID_FINISH_SURFACE		Contextual Tabs>Surface
Place Point	ID_SURFACE_POINTS		Contextual Tabs>Tools
Create from Import:Select Import Instance	ID_SITE_IMPORT		Contextual Tabs>Tools
Create from Import:Specify Points File	ID_SITE_IMPORT_POINTS		Contextual Tabs>Tools
Simplify Surface	ID_SITE_SIMPLIFY_SURFACE		Contextual Tabs>Tools
Add to Group	ID_EDITGROUP_ATTACH_ELEM_TO_GROUP		Contextual Tabs>Edit Attached Group
Remove from Group	ID_EDITGROUP_DETACH_ELEM_FROM_GROUP		Contextual Tabs>Edit Attached Group
Finish	ID_FINISH_ATTACHED_GROUP_EDIT_MODE		Contextual Tabs>Edit Attached Group
Cancel	ID_CANCEL_ATTACHED_GROUP_EDIT_MODE		Contextual Tabs>Edit Attached Group
Cancel Edit Mode	ID_QUIT_SKETCH_PATH		Contextual Tabs>Mode
Finish Edit Mode	ID_FINISH_SKETCH_PATH		Contextual Tabs>Mode
Add to Circuit	ID_RBS_CIRCUIT_GROUP_EDIT_ADD_TO_GROUP		Contextual Tabs>Edit Circuit
Remove from Circuit	ID_RBS_CIRCUIT_GROUP_EDIT_REMOVE_FROM_GROUP		Contextual Tabs>Edit Circuit
Select Panel	ID_RBS_CIRCUIT_GROUP_EDIT_PANEL_SELECT		Contextual Tabs>Edit Circuit
Run	ID_RUN		Contextual Tabs>Draw
Boundary	ID_BUTTON_STAIRS_BOUNDARY		Contextual Tabs>Draw
Options	ID_CPWTCH_SETTINGS		Contextual Tabs>Tools
Copy	ID_CPWTCH_COPY		Contextual Tabs>Tools
Monitor	ID_CPWTCH_WATCH		Contextual Tabs>Tools
Batch Copy	ID_FIND_FIXTURES		Contextual Tabs>Tools
Finish	ID_CPWTCH_FINISH		Contextual Tabs>Copy/Monitor
Cancel	ID_CPWTCH_QUIT		Contextual Tabs>Copy/Monitor
Add to Assembly	ID_ADD_ELEMENT_TO_ASSEMBLY		Contextual Tabs>Edit Assembly
Remove from Assembly	ID_REMOVE_ELEMENT_FROM_ASSEMBLY		Contextual Tabs>Edit Assembly
Finish	ID_FINISH_ASSEMBLY_EDIT		Contextual Tabs>Edit Assembly
Cancel	ID_CANCEL_ASSEMBLY_EDIT		Contextual Tabs>Edit Assembly
Auto Ceiling	ID_AUTO_CEILING		Contextual Tabs>Tools
Snap to Sheet	ID_SNAP_TO_SHEET		Contextual Tabs>GuideGrid; Contextual Tabs>Viewport
Create Form	ID_CREATEFORMELEM		Contextual Tabs>Form

Create Form:Void Form	ID_CREATEVOIDFORM	Contextual Tabs>Form
Sketch	ID_OBJECTS_VOLUME_DIVIDER_SKETCH	Contextual Tabs>Division
Objects to Divide	ID_OBJECTS_VOLUME_DIVIDER_OBJECTS_TO_DIVIDE	Contextual Tabs>Division
Intersects:Intersects	ID_DIVIDED_ELEMENT_INTRST_PICK	Contextual Tabs>Division
Intersects:Intersecting References	ID_DIVIDED_ELEMENT_INTRST_LIST	Contextual Tabs>Division
Disable Analytical Model	ID_DISABLE_ANALYTICAL_MODEL	Contextual Tabs>Analytical Model Tools
Analytical Reset	ID_RESET_SELECTED_ANALYTICAL_MODEL	Contextual Tabs>Analytical Model Tools
Reset Analytical Links	ID_RESET_ANALYTICAL_LINKS	Contextual Tabs>Analytical Model Tools
Reset Manual Edge Offsets	ID_CLEAN_MANUALLY_ADJUSTED	Contextual Tabs>Edge Horizontal Alignment
Edit Division	ID_OBJECTS_VOLUME_EDIT_DIVISION	Contextual Tabs>Part
Edit Merged Part	ID_MERGED_PART_EDIT	Contextual Tabs>Part
Reset Shape	ID_OBJECTS_PARTS_RESET	Contextual Tabs>Part
Divide Parts	ID_OBJECTS_DIVIDE	Contextual Tabs>Part
Merge Parts	ID_OBJECTS_MERGE	Contextual Tabs>Part
Show Host	ID_SHOW_HOST	Contextual Tabs>Host
Select Host	ID_SELECT_HOST	Contextual Tabs>Host
Pick New Host	ID_PICK_HOST_IND_TAG	Contextual Tabs>Host
Divide Surface; Divide Surface	ID_OBJECTS_DIVIDED_SURFACE //	Contextual Tabs>Divide
Divide Path; Divide Path	ID_DIVIDE_PATH	Contextual Tabs>Divide
Edit Rail	ID_EDIT_CONTINUOUS_RAIL	Contextual Tabs>Continuous Rail
Reset Railing	ID_RESET_RAILING	Contextual Tabs>Tools
Exclude Parts	ID_EXCLUDE_PART	Contextual Tabs>Exclude
Restore Parts	ID_RESTORE_PART	Contextual Tabs>Exclude
Remove Area Reinforcement System	ID_REMOVE_AREA_REINFORCEMENT_SYSTEM	Contextual Tabs>Area Reinforcement
Remove Path Reinforcement System	ID_REMOVE_PATH_REINFORCEMENT_SYSTEM	Contextual Tabs>Path Reinforcement
Remove Fabric Area Reinforcement System	ID_REMOVE_FABRIC_REINFORCEMENT_SYSTEM	Contextual Tabs>Fabric Area Reinforcement
Select Tag	ID_MULTI_REFERENCE_ANNOTATION_SELECT_TAG	Contextual Tabs>Edit
Select Dimension	ID_MULTI_REFERENCE_ANNOTATION_SELECT_DIMENSION	Contextual Tabs>Edit
Duct Pressure Loss Report	ID_MEP_SELECT_DUCT_PRESSURE_LOSS_REPORT	Contextual Tabs>Duct System Reports
Pipe Pressure Loss Report	ID_MEP_SELECT_PIPE_PRESSURE_LOSS_REPORT	Contextual Tabs>Pipe System Reports
Air Terminal on Duct	ID_RBS_MECHANICAL_DIFFUSER_TO_DUCT	Contextual Tabs>Layout
Change End Reference	ID_CHANGE_BEAM_END_REFERENCE	Contextual Tabs>Modify End
Justification Points	ID_STRUCT_JUST_EDITOR_CARDINAL JP	Contextual Tabs>Justification
Justification Offset	ID_STRUCT_JUST_EDITOR_OFFSET	Contextual Tabs>Justification
Offset:y Offset	ID_STRUCT_JUST_EDITOR_OFFSET_Y JY	Contextual Tabs>Justification
Offset:z Offset	ID_STRUCT_JUST_EDITOR_OFFSET_Z JZ	Contextual Tabs>Justification
Elbows	ID_OVERRIDE_FAB_PART_BENDS	Contextual Tabs>Override
Tees	ID_OVERRIDE_FAB_PART_TEES	Contextual Tabs>Override
Crosses	ID_OVERRIDE_FAB_PART_CROSSES	Contextual Tabs>Override
Restore Size	ID_RESTORE_IMAGE_SIZE	Contextual Tabs>Image
Resize	ID_RESIZE_IMAGE_ROWS	Contextual Tabs>Image
Remove Repeater	ID_COMPONENTREPEATER_REMOVEPEATER	Contextual Tabs>Repeater
Change Template	Dialog_BuildingSystems_PanelScheduleTemplateDlgbar:Control_Building	Contextual Tabs>Template
Duct	Dialog_BuildingSystems_RbsCreateHvacSystemGroup:Control_BuildingSy	Contextual Tabs>Create Systems
Power	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Data	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Telephone	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Security	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Fire Alarm	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Nurse Call	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Controls	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Communication	Dialog_BuildingSystems_RbsCreateCircuitGroup:Control_BuildingSystems	Contextual Tabs>Create Systems
Piping	Dialog_BuildingSystems_RbsCreatePipingSystemGroup:Control_BuildingS	Contextual Tabs>Create Systems
Switch	Dialog_BuildingSystems_RbsCreateSwitchSystem:Control_BuildingSystem	Contextual Tabs>Create Systems

System Inspector	Dialog_BuildingSystems_RbsSystemInspectBar:Control_BuildingSystems_Contextual Tabs>Analysis
Duct/Pipe Sizing	Dialog_BuildingSystems_RbsDuctSizingBar:Control_BuildingSystems_RbsContextual Tabs>Analysis
Edit System	Dialog_BuildingSystems_RbsEditSystemGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Select Equipment	Dialog_BuildingSystems_RbsEditSystemGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Disconnect Equipment	Dialog_BuildingSystems_RbsEditSystemGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Divide System	Dialog_BuildingSystems_RbsEditSystemGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Edit Circuit	Dialog_BuildingSystems_RbsEditCircuitGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Select Panel	Dialog_BuildingSystems_RbsEditCircuitGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Disconnect Panel	Dialog_BuildingSystems_RbsEditCircuitGroup:Control_BuildingSystems_Contextual Tabs>System Tools
Edit System	Dialog_BuildingSystems_EditPipingSystemGroup:Control_BuildingSystem Contextual Tabs>System Tools
Select Equipment	Dialog_BuildingSystems_EditPipingSystemGroup:Control_BuildingSystem Contextual Tabs>System Tools
Disconnect Equipment	Dialog_BuildingSystems_EditPipingSystemGroup:Control_BuildingSystem Contextual Tabs>System Tools
Divide System	Dialog_BuildingSystems_EditPipingSystemGroup:Control_BuildingSystem Contextual Tabs>System Tools
Edit Switch System	Dialog_BuildingSystems_RbsEditSwitchSystem:Control_BuildingSystems_Contextual Tabs>System Tools
Select Switch	Dialog_BuildingSystems_RbsEditSwitchSystem:Control_BuildingSystems_Contextual Tabs>System Tools
Disconnect Switch	Dialog_BuildingSystems_RbsEditSwitchSystem:Control_BuildingSystems_Contextual Tabs>System Tools
Justification	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Placement Tools
Automatically Connect	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Placement Tools
Inherit Elevation	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Placement Tools
Inherit Size	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Placement Tools
Add Vertical	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Offset Connections
Change Slope	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Offset Connections
Tag on Placement	Dialog_BuildingSystems_RbsLayoutOptionsBar:Control_BuildingSystems_Contextual Tabs>Tag
Slope: Off	ID_SLOPE_PIPE_OFF Contextual Tabs>Sloped Piping
Slope: Up	ID_SLOPE_PIPE_UP Contextual Tabs>Sloped Piping
Slope: Down	ID_SLOPE_PIPE_DOWN Contextual Tabs>Sloped Piping
Show Slope Tooltip	ID_SLOPE_PIPE_SHOW_TOOLTIP Contextual Tabs>Sloped Piping
Generate Layout	Dialog_BuildingSystems_RbsLayoutpathBar:Control_BuildingSystems_RbsContextual Tabs>Layout
Generate Placeholder	Dialog_BuildingSystems_RbsLayoutpathBar:Control_BuildingSystems_RbsContextual Tabs>Layout
Connect Into	Dialog_BuildingSystems_RbsConnectIntoBar:Control_BuildingSystems_RbsContextual Tabs>Layout
Routing Solutions	Dialog_BuildingSystems_RbsRoutePathEdit:Control_BuildingSystems_RbsContextual Tabs>Layout
Create Panel Schedules	Dialog_BuildingSystems_RbsPanelScheduleCreateupdateDlgbar:Control_BuildingSystems_Contextual Tabs>Electrical
Create Panel Schedules	Dialog_BuildingSystems_RbsPanelScheduleCreateupdateDlgbar:Control_BuildingSystems_Contextual Tabs>Electrical
Edit Panel Schedule	Dialog_BuildingSystems_RbsPanelScheduleCreateupdateDlgbar:Control_BuildingSystems_Contextual Tabs>Electrical
Justify	Dialog_BuildingSystems_RbsRoutePathJustify:Control_BuildingSystems_RbsContextual Tabs>Edit
Slope	Dialog_BuildingSystems_RbsRoutePathSlope:Control_BuildingSystems_RbsContextual Tabs>Edit
Change Type	Dialog_BuildingSystems_ChangeCurveType:Control_BuildingSystems_ChangeContextual Tabs>Edit
Reapply Type	Dialog_BuildingSystems_ChangeCurveType:Control_BuildingSystems_ChangeContextual Tabs>Edit
Convert Placeholder	Dialog_BuildingSystems_ConvertPlaceHolder:Control_BuildingSystems_ConvertContextual Tabs>Edit
Cap Open Ends	Dialog_BuildingSystems_AddCap:Control_BuildingSystems_AddCap Contextual Tabs>Edit
Add Vertical	Dialog_BuildingSystems_3dSnapping:Control_BuildingSystems_MaintainContextual Tabs>Offset Connections
Change Slope	Dialog_BuildingSystems_3dSnapping:Control_BuildingSystems_3dSnappingContextual Tabs>Offset Connections
Placeholders	Dialog_BuildingSystems_RbsRoutePathModify:Control_BuildingSystems_Contextual Tabs>Solution Geometry
3D Elements	Dialog_BuildingSystems_RbsRoutePathModify:Control_BuildingSystems_Contextual Tabs>Solution Geometry
Finish	Dialog_BuildingSystems_RbsRoutePathModify:Control_BuildingSystems_Contextual Tabs>Routing Solutions
Cancel	Dialog_BuildingSystems_RbsRoutePathModify:Control_BuildingSystems_Contextual Tabs>Routing Solutions
Arc Wire	Dialog_BuildingSystems_RbsWireConversionBar:Control_BuildingSystems_Contextual Tabs>Convert to Wire
Chamfered Wire	Dialog_BuildingSystems_RbsWireConversionBar:Control_BuildingSystems_Contextual Tabs>Convert to Wire
Edit Zone	Dialog_BuildingSystems_RbsZoneEditBar:Control_BuildingSystems_RbsZoneContextual Tabs>Zone
All Segments	Dialog_CurtainGridFamily_CurtainGridDialog:Control_CurtainGridFamily_Contextual Tabs>Placement
One Segment	Dialog_CurtainGridFamily_CurtainGridDialog:Control_CurtainGridFamily_Contextual Tabs>Placement
All Except Picked	Dialog_CurtainGridFamily_CurtainGridDialog:Control_CurtainGridFamily_Contextual Tabs>Placement
Restart Curtain Grid	Dialog_CurtainGridFamily_CurtainGridDialog:Control_CurtainGridFamily_Contextual Tabs>Placement
Select Multiple	Dialog_CurtainGridFamily_CurtainGridDialog:Control_CurtainGridFamily_Contextual Tabs>Multiple Selection

Clear Selection	Dialog_CurtainGridFamily_CurtasysByFaceDbar:Control_CurtainGridFami	Contextual Tabs>Multiple Selection
Create System	Dialog_CurtainGridFamily_CurtasysByFaceDbar:Control_CurtainGridFami	Contextual Tabs>Multiple Selection
Clear Selection	Dialog_CurtainGridFamily_CurtasysByFaceEditDbar:Control_CurtainGridF	Contextual Tabs>Multiple Selection
Recreate System	Dialog_CurtainGridFamily_CurtasysByFaceEditDbar:Control_CurtainGridF	Contextual Tabs>Multiple Selection
Edit Face Selection	Dialog_CurtainGridFamily_CurtaSystemEdit:Control_CurtainGridFamily_E	Contextual Tabs>Model by Face
Update to Face	Dialog_CurtainGridFamily_CurtaSystemEdit:Control_CurtainGridFamily_R	Contextual Tabs>Model by Face
Make Continuous	Dialog_CurtainGridFamily_MullionJoinsBar:Control_CurtainGridFamily_Sc	Contextual Tabs>Mullion
Break at Join	Dialog_CurtainGridFamily_MullionJoinsBar:Control_CurtainGridFamily_Sc	Contextual Tabs>Mullion
Grid Line	Dialog_CurtainGridFamily_MullionPlacement:Control_CurtainGridFamily_	Contextual Tabs>Placement
Grid Line Segment	Dialog_CurtainGridFamily_MullionPlacement:Control_CurtainGridFamily_	Contextual Tabs>Placement
All Grid Lines	Dialog_CurtainGridFamily_MullionPlacement:Control_CurtainGridFamily_	Contextual Tabs>Placement
Edit Label	Dialog_Detail_TagNoteDlgBar:Control_Detail_EditSubstitutionText	Contextual Tabs>Label
Align Left	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignLeft	Contextual Tabs>Format
Align Center	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignCenter	Contextual Tabs>Format
Align Right	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignRight	Contextual Tabs>Format
Align Top	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignTop	Contextual Tabs>Format
Center Middle	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignMiddle	Contextual Tabs>Format
Align Bottom	Dialog_Detail_TagNoteUiDlgBar:Control_Detail_AlignBottom	Contextual Tabs>Format
Add Left Side Straight Leader	Dialog_Detail_TextNoteDlgBar:Control_Detail_TextnoteAddleader	Contextual Tabs>Format
Add Right Side Straight Leader	Dialog_Detail_TextNoteDlgBar:Control_Detail_TextnoteAddleaderR	Contextual Tabs>Format
Add Left Side Arc Leader	Dialog_Detail_TextNoteDlgBar:Control_Detail_TextnoteAddLeaderArc	Contextual Tabs>Format
Add Right Side Arc Leader	Dialog_Detail_TextNoteDlgBar:Control_Detail_TextnoteAddLeaderArcR	Contextual Tabs>Format
Remove Last Leader	Dialog_Detail_TextNoteDlgBar:Control_Detail_TextnoteRmvleader	Contextual Tabs>Format
Leader at Top Left	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderTopLeft	Contextual Tabs>Format
Leader at Middle Left	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderMiddleLeft	Contextual Tabs>Format
Leader at Bottom Left	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderBottomLeft	Contextual Tabs>Format
Leader at Top Right	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderTopRight	Contextual Tabs>Format
Leader at Middle Right	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderMiddleRight	Contextual Tabs>Format
Leader at Bottom Right	Dialog_Detail_TextNoteDlgBar:Control_Detail_LeaderBottomRight	Contextual Tabs>Format
Align Left	Dialog_Detail_TextNoteDlgBar:Control_Detail_AlignLeft	Contextual Tabs>Format
Align Center	Dialog_Detail_TextNoteDlgBar:Control_Detail_AlignCenter	Contextual Tabs>Format
Align Right	Dialog_Detail_TextNoteDlgBar:Control_Detail_AlignRight	Contextual Tabs>Format
Paragraph Format	Dialog_Revit_TextRtfUi:Control_Revit_TextParaFormatNone	Contextual Tabs>Format
Paragraph Format	Dialog_Revit_TextRtfUi:Control_Revit_TextParaFormatBullet	Contextual Tabs>Format
Paragraph Format	Dialog_Revit_TextRtfUi:Control_Revit_TextParaFormatNumber	Contextual Tabs>Format
Paragraph Format	Dialog_Revit_TextRtfUi:Control_Revit_TextParaFormatLowercase	Contextual Tabs>Format
Paragraph Format	Dialog_Revit_TextRtfUi:Control_Revit_TextParaFormatUppercase	Contextual Tabs>Format
Bold	Dialog_Revit_TextRtfUi:Control_Revit_TextBold	Contextual Tabs>Format
Italic	Dialog_Revit_TextRtfUi:Control_Revit_TextItalic	Contextual Tabs>Format
Underline	Dialog_Revit_TextRtfUi:Control_Revit_TextUnderline	Contextual Tabs>Format
Align Left	Dialog_Detail_TextNoteUiDlgBarFamily:Control_Detail_AlignLeft	Contextual Tabs>Format
Align Center	Dialog_Detail_TextNoteUiDlgBarFamily:Control_Detail_AlignCenter	Contextual Tabs>Format
Align Right	Dialog_Detail_TextNoteUiDlgBarFamily:Control_Detail_AlignRight	Contextual Tabs>Format
No Leader	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_TextLeaderNone	Contextual Tabs>Format
One Segment	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_TextLeaderOneseg	Contextual Tabs>Format
Two Segments	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_TextLeaderTwoseg	Contextual Tabs>Format
Curved	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_TextLeaderArc	Contextual Tabs>Format
Leader at Top Left	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderTopLeft	Contextual Tabs>Format
Leader at Middle Left	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderMiddleLeft	Contextual Tabs>Format
Leader at Bottom Left	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderBottomLeft	Contextual Tabs>Format
Leader at Top Right	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderTopRight	Contextual Tabs>Format
Leader at Middle Right	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderMiddleRight	Contextual Tabs>Format
Leader at Bottom Right	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_LeaderBottomRight	Contextual Tabs>Format
Align Left	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_AlignLeft	Contextual Tabs>Format

Align Center	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_AlignCenter	Contextual Tabs>Format
Align Right	Dialog_Detail_TextNoteUiDlgBarNew:Control_Detail_AlignRight	Contextual Tabs>Format
Edit Group	ID_EDITGROUP_GROUP_EDIT EG	Contextual Tabs>Group
Ungroup	ID_EDITGROUP_UNGROUP UG	Contextual Tabs>Group
Link	ID_REPLACE_GROUP_WITH_LINK LG	Contextual Tabs>Group
Attached Detail Groups	Dialog_ElementGroup_EditGroupNew:Control_ElementGroup_EditGroup	Contextual Tabs>Group
Detach from Model Group	Dialog_ElementGroup_EditGroupNew:Control_ElementGroup_EditGroup	Contextual Tabs>Group
Restore All Excluded	ID_RESTORE_ALL_EXCLUDED RA	Contextual Tabs>Group; Context Menu
Edit Scheme	Dialog_Essentials_ColorFillDlgBar:Control_Essentials_EditColorScheme	Contextual Tabs>Scheme
Visibility Settings	Dialog_Essentials_CurveVisibilityDbar:Control_Essentials_Visibility	Contextual Tabs>Visibility
Propagate Extents	Dialog_Essentials_DatumOptionBar:Control_Essentials_DatumPropagateI	Contextual Tabs>Datum
Edit Witness Lines	IDC_EDIT_WITNESS_REFS EW	Contextual Tabs>Witness Lines
Edit Top	Dialog_Essentials_EditBlend:Control_Essentials_EditSketch2	Contextual Tabs>Mode
Edit Base	Dialog_Essentials_EditBlend:Control_Essentials_EditSketch	Contextual Tabs>Mode
Visibility Settings	Dialog_Essentials_EditBlend:Control_Essentials_SketchVisibility	Contextual Tabs>Mode
Edit Sweep	Dialog_Essentials_EditSweep:Control_Essentials_EditSweep	Contextual Tabs>Mode
Visibility Settings	Dialog_Essentials_EditSweep:Control_Essentials_SketchVisibility	Contextual Tabs>Mode
Edit Swept Blend	Dialog_Essentials_EditSweptBlend:Control_Essentials_EditSweptBlend	Contextual Tabs>Mode
Visibility Settings	Dialog_Essentials_EditSweptBlend:Control_Essentials_SketchVisibility	Contextual Tabs>Mode
Edit Model Text	Dialog_Essentials_EditTextDbar:Control_Essentials_EditText	Contextual Tabs>Text
Edit Model Text	Dialog_Essentials_EditTextVisDbar:Control_Essentials_EditText	Contextual Tabs>Text
Visibility Settings	Dialog_Essentials_EditTextVisDbar:Control_Essentials_Visibility	Contextual Tabs>Text
Visibility Settings	Dialog_Essentials_ElemVisibilityDbar:Control_Essentials_SketchVisibility	Contextual Tabs>Visibility
Filter	Dialog_Essentials_FilterSelection:Control_Essentials_BtnFilterSelection	Contextual Tabs>Filter
Unhide Element	ID_VIEW_UNHIDE_ELEMENTS EU	Contextual Tabs>Reveal Hidden Elements
Unhide Category	ID_VIEW_UNHIDE_BY_CATEGORY VU	Contextual Tabs>Reveal Hidden Elements
Toggle Reveal Hidden Elements Mode	ID_VIEW_FRAME_REVEALHIDDEN RH	Contextual Tabs>Reveal Hidden Elements; View Control Bar
Place on Vertical Face; Place on Vertical Face	Dialog_Essentials_GenhostCreate:Control_Essentials_PlaceByInsert	Contextual Tabs>Placement
Place on Face; Place on Face	Dialog_Essentials_GenhostCreate:Control_Essentials_PlaceByXface	Contextual Tabs>Placement
Place on Work Plane; Place on Work Plane	Dialog_Essentials_GenhostCreate:Control_Essentials_PlaceByWorkplane	Contextual Tabs>Placement
Delete Layers	Dialog_Essentials_ImportInstanceExplode:Control_Essentials_ImportDele	Contextual Tabs>Import Instance
Explode	Dialog_Essentials_ImportInstanceExplode:Control_Essentials_ImportPart	Contextual Tabs>Import Instance
Explode	Dialog_Essentials_ImportInstanceExplode:Control_Essentials_ImportExpli	Contextual Tabs>Import Instance
Query	Dialog_Essentials_ImportInstanceExplode:Control_Essentials_ImportQue	Contextual Tabs>Import Instance
Visibility Settings	Dialog_Essentials_ImportInstanceExplode:Control_Essentials_SketchVisib	Contextual Tabs>Import Instance
Pick New Host	Dialog_Essentials_IndependentTagDlgBar:Control_Essentials_PickHostInc	Contextual Tabs>Host
Light Source Definition	Dialog_Essentials_LightSourceDefinitionDlgBar:Control_Essentials_LightsI	Contextual Tabs>Lighting
Dissolve	Dialog_Essentials_ModifyCurveDbar:Control_Essentials_CurveByPointsDi	Contextual Tabs>Modify Line
Edit Pasted Elements	Dialog_Essentials_PasteMode:Control_Essentials_PasteEditMode	Contextual Tabs>Edit Pasted
Finish	Dialog_Essentials_PasteMode:Control_Essentials_FinishPaste	Contextual Tabs>Edit Pasted
Cancel	Dialog_Essentials_PasteMode:Control_Essentials_QuitPaste	Contextual Tabs>Edit Pasted
View Range	Dialog_Essentials_PlanRegionViewRange:Control_Essentials_EditViewRar	Contextual Tabs>Region
Make Adaptive	Dialog_Essentials_PointElementFlexGeomDbar:Control_Essentials_PointE	Contextual Tabs>Adaptive Component
Re-assign Primary	Dialog_Essentials_RbsConnectorLinkConnectorBar:Control_Essentials_Rb	Contextual Tabs>Primary Connector
Link Connectors	Dialog_Essentials_RbsConnectorLinkConnectorBar:Control_Essentials_Rb	Contextual Tabs>Connector Links
Remove Link	Dialog_Essentials_RbsConnectorLinkConnectorBar:Control_Essentials_Rb	Contextual Tabs>Connector Links
Place on Face	Dialog_Essentials_RbsConnectorPlacementBar:Control_Essentials_PlaceB	Contextual Tabs>Placement
Place on Work Plane	Dialog_Essentials_RbsConnectorPlacementBar:Control_Essentials_PlaceB	Contextual Tabs>Placement
Coordination Review	Dialog_Essentials_ReconcileRvtLink:Control_Essentials_ReconcileCurrentI	Contextual Tabs>Monitor
Pick New Host	Dialog_Essentials_RehostPoint:Control_Essentials_RehostPoint	Contextual Tabs>Host
Bind Link	Dialog_Essentials_RvtLinkInstanceStdDbar:Control_Essentials_BindLinkAs	Contextual Tabs>Link
Split Segment	Dialog_Essentials_SectionBar:Control_Essentials_SplitSectionSegment	Contextual Tabs>Section
Edit Sketch; Edit Boundary; Edit Footprint; Edit Path	Dialog_Essentials_SketchEdit:Control_Essentials_EditSketch	Contextual Tabs>Mode
Edit Revolve; Edit Boundary	Dialog_Essentials_SketchEditVisib:Control_Essentials_EditSketch	Contextual Tabs>Mode

Visibility Settings	Dialog_Essentials_SketchEditVisib:Control_Essentials_SketchVisibility	Contextual Tabs>Mode
Edit Extrusion	Dialog_Essentials_SketchEditVisibDepth:Control_Essentials_EditSketch	Contextual Tabs>Mode
Visibility Settings	Dialog_Essentials_SketchEditVisibDepth:Control_Essentials_SketchVisibili	Contextual Tabs>Mode
Add Control	Dialog_Essentials_SplineEdit:Control_Essentials_SplineAddControl	Contextual Tabs>Edit Spline
Delete Control	Dialog_Essentials_SplineEdit:Control_Essentials_SplineDeleteControl	Contextual Tabs>Edit Spline
Tag on Placement	Dialog_Essentials_TagOnPlacement:Control_Essentials_TagOnPlacement	Contextual Tabs>Tag
Twist Right	Dialog_Essentials_VertexLinksDbar:Control_Essentials_ShiftCw	Contextual Tabs>Vertex Connect
Twist Left	Dialog_Essentials_VertexLinksDbar:Control_Essentials_ShiftCcw	Contextual Tabs>Vertex Connect
Reset Vertex Connect	Dialog_Essentials_VertexLinksDbar:Control_Essentials_ResetVtxConnecti	Contextual Tabs>Vertex Connect
Controls on Base	Dialog_Essentials_VertexLinksDbar:Control_Essentials_VtxCtrlOnLoop0	Contextual Tabs>Vertex Connect
Controls on Top	Dialog_Essentials_VertexLinksDbar:Control_Essentials_VtxCtrlOnLoop1	Contextual Tabs>Vertex Connect
Finish Walkthrough	Dialog_Essentials_WalkthroughFinish:Control_Essentials_CancelEditor	Contextual Tabs>Walkthrough
Pick New Host	Dialog_Family_EditInsertRehostDbar:Control_Family_EditInsertRehost	Contextual Tabs>Host
Edit In-Place	Dialog_Family_FamInstDbar:Control_Family_EditInplaceFam	Contextual Tabs>Model
Edit In-Place RvtLink	Dialog_Family_FamInstDbarRvtLink:Control_Family_EditInplaceFamRvtLir	Contextual Tabs>Model1
Pick New Work Plane	Dialog_Family_FamInstGridDbar:Control_Family_PickHost	Contextual Tabs>Work Plane
Add Leader	Dialog_Family_FamInstLeaderDlgbar:Control_Family_FamInstAddleader	Contextual Tabs>Leader
Remove Leader	Dialog_Family_FamInstLeaderDlgbar:Control_Family_FamInstRmveleader	Contextual Tabs>Leader
Pick Primary Host	Dialog_Family_FamInstMultihostPickMain:Control_Family_PickMainHost	Contextual Tabs>Host
Pick New Host	Dialog_Family_FamInstOffsetDbar:Control_Family_PickHost	Contextual Tabs>Host
Edit In-Place	Dialog_Family_FamInstPanelDbar:Control_Family_EditInplaceFam	Contextual Tabs>Model
Model In-place	Dialog_Family_ManyInstDbar:Control_Family_NewInplaceAny	Contextual Tabs>Mode
At Grid Intersection	Dialog_Family_NewIsoFooting:Control_Family_CreateFootingByGridInter	Contextual Tabs>Multiple
At Structural Column	Dialog_Family_NewIsoFooting:Control_Family_CreateFootingFromStruct	Contextual Tabs>Multiple
At Grid Intersection	Dialog_Family_NewStructuralColumn:Control_Family_GridIntersection	Contextual Tabs>Multiple
At Architectural Columns	Dialog_Family_NewStructuralColumn:Control_Family_FromArchColumn	Contextual Tabs>Multiple
Single Vertical	Dialog_Family_SelectCtrlIcon:Control_Family_RadioVerArrow	Contextual Tabs>Control Type
Double Vertical	Dialog_Family_SelectCtrlIcon:Control_Family_RadioVerArrow2	Contextual Tabs>Control Type
Single Horizontal	Dialog_Family_SelectCtrlIcon:Control_Family_RadioHorArrow	Contextual Tabs>Control Type
Double Horizontal	Dialog_Family_SelectCtrlIcon:Control_Family_RadioHorArrow2	Contextual Tabs>Control Type
Horizontal	Dialog_HostObj_CorniceReveal:Control_HostObj_CorniceHorizontal	Contextual Tabs>Placement
Vertical	Dialog_HostObj_CorniceReveal:Control_HostObj_CorniceVertical	Contextual Tabs>Placement
Restart Wall Sweep; Restart Reveal	Dialog_HostObj_CorniceReveal:Control_HostObj_FinishCorniceReveal	Contextual Tabs>Placement
Edit Profile	Dialog_HostObj_SketchEditElevationRem:Control_HostObj_EditElevation:	Contextual Tabs>Mode
Reset Profile	Dialog_HostObj_SketchEditElevationRem:Control_HostObj_RemoveEleva	Contextual Tabs>Mode
Wall Opening	Dialog_HostObj_CreateWallOpening:Control_HostObj_CreateWallOpenin	Contextual Tabs>Modify Wall
Attach Top/Base	Dialog_HostObj_CreateWallOpening:Control_HostObj_ExtendWalls	Contextual Tabs>Modify Wall
Detach Top/Base	Dialog_HostObj_CreateWallOpening:Control_HostObj_UnextendWalls	Contextual Tabs>Modify Wall
Finish	Dialog_HostObj_DividedPathEditRefSelectionDbar:Control_HostObj_Divic	Contextual Tabs>Intersects
Cancel	Dialog_HostObj_DividedPathEditRefSelectionDbar:Control_HostObj_Divic	Contextual Tabs>Intersects
U Grid	Dialog_HostObj_DividedSurfaceDirection1Bar:Control_HostObj_Gridlines	Contextual Tabs>UV Grids and Intersects
V Grid	Dialog_HostObj_DividedSurfaceDirection1Bar:Control_HostObj_Gridlines	Contextual Tabs>UV Grids and Intersects
Intersects	Dialog_HostObj_DividedSurfaceDirection1Bar:Control_HostObj_IntrstPicl	Contextual Tabs>UV Grids and Intersects
Intersects	Dialog_HostObj_DividedSurfaceDirection1Bar:Control_HostObj_IntrstList	Contextual Tabs>UV Grids and Intersects
Surface	Dialog_HostObj_DividedSurfaceDisplayPropertiesBar:Control_HostObj_SI	Contextual Tabs>Surface Representation
Pattern	Dialog_HostObj_DividedSurfaceDisplayPropertiesBar:Control_HostObj_SI	Contextual Tabs>Surface Representation
Component	Dialog_HostObj_DividedSurfaceDisplayPropertiesBar:Control_HostObj_SI	Contextual Tabs>Surface Representation
Finish	Dialog_HostObj_DividedSurfaceEditRefSelectionDbar:Control_HostObj_D	Contextual Tabs>Intersects
Cancel	Dialog_HostObj_DividedSurfaceEditRefSelectionDbar:Control_HostObj_D	Contextual Tabs>Intersects
Add/Remove Walls	Dialog_HostObj_EditCornice:Control_HostObj_EditWallSweep	Contextual Tabs>Wall Sweep
Modify Returns	Dialog_HostObj_EditCornice:Control_HostObj_ChangeSweepReturns	Contextual Tabs>Wall Sweep
Add/Remove Segments	Dialog_HostObj_EditCurtainGridDialog:Control_HostObj_CurtaGridLineAr	Contextual Tabs>Curtain Grid
Edit Dormer Opening	Dialog_HostObj_EditDormerOpening:Control_HostObj_EditDormerOpeni	Contextual Tabs>Opening
Add/Remove Segments	Dialog_HostObj_EditMiterSweepHostDialog:Control_HostObj_EditSweep	Contextual Tabs>Roof Fascia

Modify Mitering	Dialog_HostObj_EditMiterSweepHostDialog:Control_HostObj_MiterSweep	Contextual Tabs>Roof Fascia
Add/Remove Walls	Dialog_HostObj_EditReveal:Control_HostObj_EditWallSweep	Contextual Tabs>Reveal
Modify Returns	Dialog_HostObj_EditReveal:Control_HostObj_ChangeSweepReturns	Contextual Tabs>Reveal
Add/Remove Segments	Dialog_HostObj_EditSweepHostDialog:Control_HostObj_EditSweepHost	Contextual Tabs>Profile
Modify Returns	Dialog_HostObj_EditWallSweepReturns:Control_HostObj_ChangeSweepF	Contextual Tabs>Wall Sweep
Edit Face Selection	Dialog_HostObj_FaceRoofEdit:Control_HostObj_EditFaceRoof	Contextual Tabs>Model by Face
Update to Face	Dialog_HostObj_FaceRoofEdit:Control_HostObj_RedoFaceRoof	Contextual Tabs>Model by Face
Select Multiple	Dialog_HostObj_FloorByFaceDbar:Control_HostObj_SelMultiCheck	Contextual Tabs>Multiple Selection
Clear Selection	Dialog_HostObj_FloorByFaceDbar:Control_HostObj_CancelMultiPickDbar	Contextual Tabs>Multiple Selection
Create Floor	Dialog_HostObj_FloorByFaceDbar:Control_HostObj_FinishMultiPickDbar	Contextual Tabs>Multiple Selection
Vertical	Dialog_HostObj_MiterSweepHostDialog:Control_HostObj_MiterVertical	Contextual Tabs>Mitering
Horizontal	Dialog_HostObj_MiterSweepHostDialog:Control_HostObj_MiterHorizontal	Contextual Tabs>Mitering
Perpendicular	Dialog_HostObj_MiterSweepHostDialog:Control_HostObj_MiterNormalT	Contextual Tabs>Mitering
Edit Sketch	Dialog_HostObj_OpeningDbar:Control_HostObj_EditSketch	Contextual Tabs>Opening
Edit Sketch	Dialog_HostObj_OpeningWRehostDbar:Control_HostObj_EditSketch1	Contextual Tabs>Mode
Pick New Host	Dialog_HostObj_OpeningWRehostDbar:Control_HostObj_PickHost	Contextual Tabs>Host
Update to Face	Dialog_HostObj_RedoFaceBased:Control_HostObj_RedoFaceBased	Contextual Tabs>Model by Face
Select Multiple	Dialog_HostObj_RoofByFaceDbar:Control_HostObj_SelMultiCheck	Contextual Tabs>Multiple Selection
Clear Selection	Dialog_HostObj_RoofByFaceDbar:Control_HostObj_CancelMultiPickDbar	Contextual Tabs>Multiple Selection
Create Roof	Dialog_HostObj_RoofByFaceDbar:Control_HostObj_FinishMultiPickDbar	Contextual Tabs>Multiple Selection
Clear Selection	Dialog_HostObj_RoofByFaceEditDbar:Control_HostObj_CancelMultiPickD	Contextual Tabs>Multiple Selection
Recreate Roof	Dialog_HostObj_RoofByFaceEditDbar:Control_HostObj_FinishMultiPickD	Contextual Tabs>Multiple Selection
Edit Profile	Dialog_HostObj_SketchEditElevation:Control_HostObj_EditElevationSke	Contextual Tabs>Mode
Attach Top/Base	Dialog_HostObj_SketchEditElevation:Control_HostObj_ExtendWalls	Contextual Tabs>Modify Wall
Detach Top/Base	Dialog_HostObj_SketchEditElevation:Control_HostObj_UnextendWalls	Contextual Tabs>Modify Wall
Attach Top/Base	Dialog_HostObj_SketchEditElevationRem:Control_HostObj_ExtendWalls	Contextual Tabs>Modify Wall
Detach Top/Base	Dialog_HostObj_SketchEditElevationRem:Control_HostObj_UnextendWa	Contextual Tabs>Modify Wall
Edit Profile	Dialog_HostObj_SketchEditPlanNoStuff:Control_HostObj_EditSketch1	Contextual Tabs>Mode
Vertical Opening	Dialog_HostObj_SketchEditPlanNoStuff:Control_HostObj_EditSketch2	Contextual Tabs>Opening
Modify Sub Elements	Dialog_HostObj_SlabShapeMainEditorBar:Control_HostObj_ModifySlabS	Contextual Tabs>Shape Editing
Add Point	Dialog_HostObj_SlabShapeMainEditorBar:Control_HostObj_DrawSlabSha	Contextual Tabs>Shape Editing
Add Split Line	Dialog_HostObj_SlabShapeMainEditorBar:Control_HostObj_DrawSlabSha	Contextual Tabs>Shape Editing
Pick Supports	Dialog_HostObj_SlabShapeMainEditorBar:Control_HostObj_PickSlabShap	Contextual Tabs>Shape Editing
Reset Shape	Dialog_HostObj_SlabShapeMainEditorBar:Control_HostObj_RemoveSlabI	Contextual Tabs>Shape Editing
Restart Fascia; Restart Gutter; Restart Slab Edge	Dialog_HostObj_SweepHostDialog:Control_HostObj_FinishSweepHost	Contextual Tabs>Placement
Related Hosts	Dialog_Massing_RelatedHosts:Control_Massing_RelatedHosts	Contextual Tabs>Model
Mass Floors	Dialog_Massing_CreateFaf:Control_Massing_CreateFaf	Contextual Tabs>Model
Show all rebars for the selection	Dialog_Rebar_EditRebarSelectionDialogBar:Control_Rebar_EditRebarSele	Contextual Tabs>Edit Rebar Presentation
Hide all rebars for the selection	Dialog_Rebar_EditRebarSelectionDialogBar:Control_Rebar_EditRebarSele	Contextual Tabs>Edit Rebar Presentation
Finish	Dialog_Rebar_EditRebarSelectionDialogBar:Control_Rebar_EditRebarSele	Contextual Tabs>Edit Rebar Presentation
Cancel	Dialog_Rebar_EditRebarSelectionDialogBar:Control_Rebar_EditRebarSele	Contextual Tabs>Edit Rebar Presentation
Place Rebar Perpendicular to Work Plane	Dialog_Rebar_RebarBeamColRst6Dbar:Control_Rebar_RebarPlacePerpen	Contextual Tabs>Reinforcement
Place Rebar Parallel to Work Plane	Dialog_Rebar_RebarBeamColRst6Dbar:Control_Rebar_RebarPlaceParalle	Contextual Tabs>Reinforcement
Place Rebar Perpendicular to Work Plane	Dialog_Rebar_RebarFloorWallRst6Dbar:Control_Rebar_RebarPlacePerpei	Contextual Tabs>Reinforcement
Place Rebar Parallel to Work Plane	Dialog_Rebar_RebarFloorWallRst6Dbar:Control_Rebar_RebarPlaceParalle	Contextual Tabs>Reinforcement
Area Reinforcement	Dialog_Rebar_RebarFloorWallRst6Dbar:Control_Rebar_RebarSystemSke	Contextual Tabs>Reinforcement
Path Reinforcement	Dialog_Rebar_RebarFloorWallRst6Dbar:Control_Rebar_PathReinSketchH	Contextual Tabs>Reinforcement
Structural Fabric Area	ID_FABRIC_DISTR_SYSTEM_SKETCH_HOST	Contextual Tabs>Reinforcement
Place with Top Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective
Place with Bottom Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective
Place with Front Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective
Place with Back Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective
Place with Right Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective
Place with Left Side Orientation Parallel to Work Plane	Dialog_Rebar_RebarPlaceMultiPlanarOrientDbar:Control_Rebar_RebarPl	Contextual Tabs>Placement Perspective

Sketch Rebar Shape on Work Plane	Dialog_Rebar_RebarPlaceclicksOrSketchDbar:Control_Rebar_RebarSketchI	Contextual Tabs>Placement Perspective; Contextual Tabs>Placement Orientation
Place Parallel to Work Plane	Dialog_Rebar_RebarPlaceParaPerpDbar:Control_Rebar_RebarPlaceParaI	Contextual Tabs>Placement Orientation
Place Perpendicular to Work Plane and Parallel to Nearest Cov	Dialog_Rebar_RebarPlaceParaPerpDbar:Control_Rebar_RebarPlacePerpP	Contextual Tabs>Placement Orientation
Place Perpendicular to Work Plane and Perpendicular to Nearest Cov	Dialog_Rebar_RebarPlaceParaPerpDbar:Control_Rebar_RebarPlacePerpe	Contextual Tabs>Placement Orientation
Pick New Host	Dialog_Rebar_RebarRehostDialogBar:Control_Rebar_RebarRehost	Contextual Tabs>Host
Edit Constraints	ID_EDIT_REBAR_JOINS	Contextual Tabs>Host
Show all Rebars in Rebar Set	ID_REBAR_PRESENTATION_ALL	Contextual Tabs>Presentation
Show First and Last Rebar in Rebar Set	ID_REBAR_PRESENTATION_FIRSTLAST	Contextual Tabs>Presentation
Show Middle Rebar in Rebar Set	ID_REBAR_PRESENTATION_MIDDLE	Contextual Tabs>Presentation
Select Rebars in Rebar Set to Show	ID_REBAR_PRESENTATION_SELECT	Contextual Tabs>Presentation
Edit Crop	Dialog_Revit_CropRegionModeBar:Control_Revit_CropRegionBarSketch	Contextual Tabs>Mode
Reset Crop	Dialog_Revit_CropRegionModeBar:Control_Revit_CropRegionBarSketchR	Contextual Tabs>Mode
Size Crop	Dialog_Revit_CropRegionBar:Control_Revit_CropRegionBarModify	Contextual Tabs>Crop
Bring to Front	Dialog_Revit_DrawOrder:Control_Revit_BringToFront	Contextual Tabs>Arrange
Bring to Front	Dialog_Revit_DrawOrder:Control_Revit_BringForward	Contextual Tabs>Arrange
Send to Back	Dialog_Revit_DrawOrder:Control_Revit_SendToBack	Contextual Tabs>Arrange
Send to Back	Dialog_Revit_DrawOrder:Control_Revit_SendBackward	Contextual Tabs>Arrange
Edit Style	ID_MODIFY_ANALYSIS_DISPLAY_STYLE	Contextual Tabs>Style
Edit Family	Dialog_Revit_EditLoadedFamilyDbar:Control_Revit_EditLoadedFam	Contextual Tabs>Mode
Edit Work Plane	Dialog_Revit_EditSketchplaneDbar:Control_Revit_EditSketchplane	Contextual Tabs>Work Plane
Pick New Work Plane	Dialog_Revit_EditWpRehostDbar:Control_Revit_EditWpRehost	Contextual Tabs>Work Plane
Show	Dialog_Revit_ExternalSheetFilter:Control_Revit_RoomScheduleFilterShov	Contextual Tabs>Filter Placeholder Sheets
Hide	Dialog_Revit_ExternalSheetFilter:Control_Revit_RoomScheduleFilterHide	Contextual Tabs>Filter Placeholder Sheets
Isolate	Dialog_Revit_ExternalSheetFilter:Control_Revit_RoomScheduleFilterIsola	Contextual Tabs>Filter Placeholder Sheets
Stop Monitoring	Dialog_Revit_RemoveWatchesDbar:Control_Revit_RemoveWatch	Contextual Tabs>Monitor
Show	Dialog_Revit_RoomScheduleFilter:Control_Revit_RoomScheduleFilterSho	Contextual Tabs>Not Placed/Unenclosed
Hide	Dialog_Revit_RoomScheduleFilter:Control_Revit_RoomScheduleFilterHid	Contextual Tabs>Not Placed/Unenclosed
Isolate	Dialog_Revit_RoomScheduleFilter:Control_Revit_RoomScheduleFilterIsol	Contextual Tabs>Not Placed/Unenclosed
Group Headers; Group Headers	Dialog_Revit_ScheduleBar:Control_Revit_GroupHeaders	Contextual Tabs>Headers; Contextual Tabs>Titles & Headers
Ungroup Headers; Ungroup Headers	Dialog_Revit_ScheduleBar:Control_Revit_UngroupHeaders	Contextual Tabs>Headers; Contextual Tabs>Titles & Headers
New Row	Dialog_Revit_ScheduleBar:Control_Revit_InsertRow	Contextual Tabs>Rows
Delete Row	Dialog_Revit_ScheduleBar:Control_Revit_DeleteRows	Contextual Tabs>Rows
Hide Columns	ID_HIDE_COLUMNS	Contextual Tabs>Columns
Unhide All Columns	ID_UNHIDE_ALL_COLUMNS	Contextual Tabs>Columns
Highlight in Model	Dialog_Revit_ScheduleBar:Control_Revit_BtnScheduleShow	Contextual Tabs>Element
Shading	ID_SCHEDULE_CELL_EDIT_SHADING	Contextual Tabs>Appearance
Borders	ID_SCHEDULE_CELL_EDIT_BORDER	Contextual Tabs>Appearance
Reset	ID_SCHEDULE_RESET_OVERRIDE	Contextual Tabs>Appearance
Font	ID_SCHEDULE_TEXT_EDIT_FONT	Contextual Tabs>Appearance
Align Horizontal:Left	ID_SCHEDULE_TEXT_HORIZONTAL_ALIGN_LEFT	Contextual Tabs>Appearance
Align Horizontal:Center	ID_SCHEDULE_TEXT_HORIZONTAL_ALIGN_CENTER	Contextual Tabs>Appearance
Align Horizontal:Right	ID_SCHEDULE_TEXT_HORIZONTAL_ALIGN_RIGHT	Contextual Tabs>Appearance
Align Vertical:Top	ID_SCHEDULE_TEXT_VERTICAL_ALIGN_TOP	Contextual Tabs>Appearance
Align Vertical:Middle	ID_SCHEDULE_TEXT_VERTICAL_ALIGN_MIDDLE	Contextual Tabs>Appearance
Align Vertical:Bottom	ID_SCHEDULE_TEXT_VERTICAL_ALIGN_BOTTOM	Contextual Tabs>Appearance
Format Unit	ID_SCHEDULE_PARAM_FORMATUNITS	Contextual Tabs>Parameters
Calculated	ID_SCHEDULE_PARAM_CALCULATE	Contextual Tabs>Parameters
Merge	ID_SCHEDULE_CELL_MERGE_UNMERGE	Contextual Tabs>Titles & Headers
Insert Image	ID_SCHEDULE_CELL_INSERT_GRAPHIC	Contextual Tabs>Titles & Headers
Clear Cell	ID_SCHEDULE_CLEAR_CELL	Contextual Tabs>Titles & Headers
Insert	ID_SCHEDULE_COLUMN_INSERT_RIGHT	Contextual Tabs>Columns
Delete	ID_SCHEDULE_COLUMN_DELETE	Contextual Tabs>Columns
Resize	ID_SCHEDULE_COLUMN_RESIZE	Contextual Tabs>Columns
Freeze Rows and Columns	ID_SCHEDULE_FREEZE_COLANDROW	Contextual Tabs>Layout

Insert:Above Selected	ID_SCHEDULE_ROW_INSERT_ABOVE	Contextual Tabs>Rows
Insert:Below Selected	ID_SCHEDULE_ROW_INSERT_BELOW	Contextual Tabs>Rows
Insert Data Row	ID_INSERT_ROW	Contextual Tabs>Rows
Delete	ID_DELETE_ROWS	Contextual Tabs>Rows
Resize	ID_SCHEDULE_ROW_RESIZE	Contextual Tabs>Rows
Explain	Dialog_Revit_ScheduleExplainErrorBar:Control_Revit_ScheduleExplainErr	Contextual Tabs>Error
Show Related Warnings	ID_SHOW_RELATED_WARNINGS	Contextual Tabs>Warning
Edit Walkthrough	Dialog_Revit_WalkthroughEdit:Control_Revit_WalkthroughEdit	Contextual Tabs>Walkthrough
Previous Key Frame	Dialog_Revit_WalkthroughModify:Control_Revit_BtnPrevCkp	Contextual Tabs>Walkthrough
Previous Frame	Dialog_Revit_WalkthroughModify:Control_Revit_BtnPrevFrame	Contextual Tabs>Walkthrough
Next Frame	Dialog_Revit_WalkthroughModify:Control_Revit_BtnNextFrame	Contextual Tabs>Walkthrough
Next Key Frame	Dialog_Revit_WalkthroughModify:Control_Revit_BtnNextCkp	Contextual Tabs>Walkthrough
Play	Dialog_Revit_WalkthroughModify:Control_Revit_BtnPlay	Contextual Tabs>Walkthrough
Open Walkthrough	Dialog_Revit_WalkthroughModify:Control_Revit_BtnEditActivateview	Contextual Tabs>Walkthrough
Reset Cameras	Dialog_Revit_WalkthroughModify:Control_Revit_BtnResetDirections	Contextual Tabs>Walkthrough
Tag on Placement	Dialog_RoomAreaPlan_AreaTagDlgBar:Control_RoomAreaPlan_TagRoom	Contextual Tabs>Tag on Placement
Highlight Boundaries	Dialog_RoomAreaPlan_RoomTagDlgBar:Control_RoomAreaPlan_ShowAll	Contextual Tabs>Room; Contextual Tabs>Spaces
Tag on Placement	Dialog_RoomAreaPlan_RoomTagDlgBar:Control_RoomAreaPlan_TagRoor	Contextual Tabs>Tag
Pick New Host	ID_PICK_HOST_ROOM_TAG	Contextual Tabs>Host
Place Spaces Automatically	Dialog_RoomAreaPlan_RoomTagDlgBar:Control_RoomAreaPlan_FindAllS	Contextual Tabs>Spaces
Sketch Ceiling	Dialog_RoomAreaPlan_SketchCeiling:Control_RoomAreaPlan_SketchCeili	Contextual Tabs>Ceiling
Add Control	Dialog_Sculpting_FormElemAddDeleteSplineControlDlgbar:Control_Sculp	Contextual Tabs>Spline
Delete Control	Dialog_Sculpting_FormElemAddDeleteSplineControlDlgbar:Control_Sculp	Contextual Tabs>Spline
Edit Profile	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormEleme	Contextual Tabs>Mode
X-Ray	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormEleme	Contextual Tabs>Form Element
Add Edge	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormElemS	Contextual Tabs>Form Element
Add Profile	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormElemC	Contextual Tabs>Form Element
Dissolve	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormElemD	Contextual Tabs>Form Element
Pick New Host	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormElemR	Contextual Tabs>Form Element
Lock Profiles	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormEleme	Contextual Tabs>Form Element
Unlock Profiles	Dialog_Sculpting_FormElementEditDlgbar:Control_Sculpting_FormEleme	Contextual Tabs>Form Element
Edit Sketch	Dialog_Site_PropertyLineEditDialog:Control_Site_EditSketch	Contextual Tabs>Property Lines
Edit Table	Dialog_Site_PropertyLineEditDialog:Control_Site_PropertyLineEditTable	Contextual Tabs>Property Lines
Edit Boundary	Dialog_Site_SiteRegionSketchEdit:Control_Site_EditSketch	Contextual Tabs>Subregion
Edit Surface	Dialog_Site_SurfaceEdit:Control_Site_EditSurface	Contextual Tabs>Surface
Sketch Beam System	Dialog_Structural_AutoBeamSystemCreateDbar:Control_Structural_Sketc	Contextual Tabs>Beam System
Remove Beam System	Dialog_Structural_BeamSystemOptionDlg:Control_Structural_ExplodeBe	Contextual Tabs>Beam System
Point Boundary Condition	Dialog_Structural_ManyBcDbar:Control_Structural_PointBc	Contextual Tabs>Boundary Conditions
Line Boundary Condition	Dialog_Structural_ManyBcDbar:Control_Structural_LineBc	Contextual Tabs>Boundary Conditions
Area Boundary Condition	Dialog_Structural_ManyBcDbar:Control_Structural_AreaBc	Contextual Tabs>Boundary Conditions
Point Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_PointLoad	Contextual Tabs>Loads
Line Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_LineLoad	Contextual Tabs>Loads
Area Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_AreaLoad	Contextual Tabs>Loads
Hosted Point Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_AutoPointLoad	Contextual Tabs>Loads
Hosted Line Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_AutoLineLoad	Contextual Tabs>Loads
Hosted Area Load	Dialog_Structural_ManyLoadsDbar:Control_Structural_AutoAreaLoad	Contextual Tabs>Loads
On Grid Lines	Dialog_Structural_NewStructuralBeam:Control_Structural_CreateBeamO	Contextual Tabs>Multiple
Align Perpendicular	Dialog_Structural_SpanSymbolPropDbar:Control_Structural_AlignSpanDii	Contextual Tabs>Align Symbol
Tag on Placement	Dialog_Structural_TagOnPlacementDlg:Control_Structural_TagOnPlacem	Contextual Tabs>Tag
Edit Profile	Dialog_Structural_TrussEditProfileSketch:Control_Structural_EditTrussSk	Contextual Tabs>Mode
Reset Profile	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_Remove	Contextual Tabs>Mode
Reset Truss	Dialog_Structural_TrussEditProfileSketch:Control_Structural_ResetTruss	Contextual Tabs>Modify Truss
Remove Truss Family	Dialog_Structural_TrussEditProfileSketch:Control_Structural_ExplodeTrus	Contextual Tabs>Modify Truss
Attach Top/Bottom	Dialog_Structural_TrussEditProfileSketch:Control_Structural_AttachTruss	Contextual Tabs>Modify Truss

Detach Top/Bottom	Dialog_Structural_TrussEditProfileSketch:Control_Structural_DetachTruss:Contextual Tabs>Modify Truss
Edit Profile	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_EditTru Contextual Tabs>Mode
Reset Truss	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_ResetTr Contextual Tabs>Modify Truss
Remove Truss Family	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_Explode Contextual Tabs>Modify Truss
Attach Top/Bottom	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_AttachT Contextual Tabs>Modify Truss
Detach Top/Bottom	Dialog_Structural_TrussEditProfileSketchRem:Control_Structural_Detach Contextual Tabs>Modify Truss
Reset Truss	Dialog_Structural_TrussMultiSelect:Control_Structural_ResetTruss Contextual Tabs>Modify Truss
Remove Truss Family	Dialog_Structural_TrussMultiSelect:Control_Structural_ExplodeTrusses Contextual Tabs>Modify Truss
Attach Top/Bottom	Dialog_Structural_TrussMultiSelect:Control_Structural_AttachTrusses Contextual Tabs>Modify Truss
Detach Top/Bottom	Dialog_Structural_TrussMultiSelect:Control_Structural_DetachTrusses Contextual Tabs>Modify Truss
Vertical Column	Dialog_Structural_VerticalSlantedColumnsDialogBar:Control_Structural_ Contextual Tabs>Placement
Slanted Column	Dialog_Structural_VerticalSlantedColumnsDialogBar:Control_Structural_ Contextual Tabs>Placement
Multi-Segment Grid	ID_OBJECTS_GRID_CHAIN Contextual Tabs>Draw
Attach Top/Base	IDD_COLUMN_ATTACH_DETACH:ID_ATTACH_COLUMNS Contextual Tabs>Modify Column
Detach Top/Base	IDD_COLUMN_ATTACH_DETACH:ID_DETACH_COLUMNS Contextual Tabs>Modify Column
Finish	IDD_MULTIPICK_DBAR:ID_FINISH_MULTI_PICK_DBAR Contextual Tabs>Multiple
Cancel	IDD_MULTIPICK_DBAR:ID_CANCEL_MULTI_PICK_DBAR Contextual Tabs>Multiple
Select Multiple	IDD_MULTIPICK_DBAR:ID_SEL_MULTI_CHECK Contextual Tabs>Multiple
Attach Top/Base	IDD_WALL_ATTACH_DETACH:ID_EXTEND_WALLS Contextual Tabs>Modify Wall
Detach Top/Base	IDD_WALL_ATTACH_DETACH:ID_UNEXTEND_WALLS Contextual Tabs>Modify Wall
Rebalance Loads	Dialog_BuildingSystems_PanelScheduleLoadDlgbar:Control_BuildingSyste Contextual Tabs>Loads
Move Up	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Move Down	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Move Across	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Move To	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Assign Spare	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Assign Space	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Remove Spare/Space	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Lock/ Unlock	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Group/ Ungroup	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Update Names	Dialog_BuildingSystems_PanelScheduleCircuitDlgbar:Control_BuildingSys Contextual Tabs>Circuits
Edit Font	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Horizontally Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Horizontally Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Horizontally Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Vertically Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Vertically Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Vertically Align	Dialog_BuildingSystems_PanelScheduleTextDlgbar:Control_BuildingSyste Contextual Tabs>Text
Edit Panel Schedule	Dialog_BuildingSystems_PanelScheduleSheetInstanceEditDlgBar:Control_ Contextual Tabs>Edit
Convert Lines	Dialog_Essentials_ConvertToModelLine:Control_Essentials_ConvertLines Contextual Tabs>Edit
Convert Lines	Dialog_Essentials_ConvertToDetailLine:Control_Essentials_ConvertLines Contextual Tabs>Edit
Convert Lines	Dialog_Essentials_ConvertToSymbolicLine:Control_Essentials_ConvertLin Contextual Tabs>Edit
Convert Lines	Dialog_Essentials_ConvertMixedTypesLines:Control_Essentials_ConvertLi Contextual Tabs>Edit
Add Insulation	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Insulation
Edit Insulation	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Insulation
Remove Insulation	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Insulation
Add Lining	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Lining
Edit Lining	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Lining
Remove Lining	Dialog_BuildingSystems_RbsInsulationLiningThickness:Control_BuildingSy Contextual Tabs>Duct Lining
Add Insulation	Dialog_BuildingSystems_RbsPipeInsulationThickness:Control_BuildingSys Contextual Tabs>Pipe Insulation
Edit Insulation	Dialog_BuildingSystems_RbsPipeInsulationThickness:Control_BuildingSys Contextual Tabs>Pipe Insulation
Remove Insulation	Dialog_BuildingSystems_RbsPipeInsulationThickness:Control_BuildingSys Contextual Tabs>Pipe Insulation
Edit Assembly	ID_RM_ASSEMBLY_EDITOR Contextual Tabs>Assembly
Disassemble	ID_ASSEMBLY_DISASSEMBLE Contextual Tabs>Assembly

Create Views	ID_CREATE_SHOP_DRAWING	Contextual Tabs>Assembly
Acquire Views	ID_ACQUIRE_ASSEMBLY_VIEWS	Contextual Tabs>Assembly
Finish	ID_FINISH_MULTI_PICK_DBAR	Contextual Tabs>Intersects
Cancel	ID_CANCEL_MULTI_PICK_DBAR	Contextual Tabs>Intersects
Horizontal Number	ID_PARALLEL_PIPES_HORIZONTAL_NUMBER	Contextual Tabs>Parallel Pipes
Vertical Number	ID_PARALLEL_PIPES_VERTICAL_NUMBER	Contextual Tabs>Parallel Pipes
Horizontal Offset	ID_PARALLEL_PIPES_HORIZONTAL_OFFSET	Contextual Tabs>Parallel Pipes
Vertical Offset	ID_PARALLEL_PIPES_VERTICAL_OFFSET	Contextual Tabs>Parallel Pipes
Same Bend Radius	ID_PARALLEL_CONDUITS_SAME_BEND_RADIUS	Contextual Tabs>Parallel Conduits
Concentric Bend Radius	ID_PARALLEL_CONDUITS_RAINBOW_BEND_RADIUS	Contextual Tabs>Parallel Conduits
Horizontal Number	ID_PARALLEL_CONDUITS_HORIZONTAL_NUMBER	Contextual Tabs>Parallel Conduits
Vertical Number	ID_PARALLEL_CONDUITS_VERTICAL_NUMBER	Contextual Tabs>Parallel Conduits
Horizontal Offset	ID_PARALLEL_CONDUITS_HORIZONTAL_OFFSET	Contextual Tabs>Parallel Conduits
Vertical Offset	ID_PARALLEL_CONDUITS_VERTICAL_OFFSET	Contextual Tabs>Parallel Conduits
Highlight Analytical Model	IDD_SHOW_ANALYTICAL_MODEL:IDC_SHOW_ANALYTICAL	Contextual Tabs>Analytical
Highlight Physical Model	IDD_SHOW_PHYSICAL_MODEL:IDC_SHOW_PHYSICAL	Contextual Tabs>Physical
Layout	Dialog_ArrayElems_DividedPathSplitReferenceBar:Control_ArrayElems_D	Contextual Tabs>Divisions and Intersects
Intersects	Dialog_ArrayElems_DividedPathSplitReferenceBar:Control_ArrayElems_Ir	Contextual Tabs>Divisions and Intersects
Intersects	Dialog_ArrayElems_DividedPathSplitReferenceBar:Control_ArrayElems_Ir	Contextual Tabs>Divisions and Intersects
Path	Dialog_ArrayElems_DividedPathDisplayPropertiesBar:Control_ArrayElem:	Contextual Tabs>Path Representation
Component	Dialog_ArrayElems_DividedPathDisplayPropertiesBar:Control_ArrayElem:	Contextual Tabs>Path Representation
Edit Family	ID_EDIT_REBAR_ELEMENT_SHAPE_FAMILY	Contextual Tabs>Mode
Pick New Host	ID_LOAD_BC_REHOST	Contextual Tabs>Host
Treads	Dialog_StairRamp_RailingPlaceOnHostDBar:Control_StairRamp_RailingPc	Contextual Tabs>Position
Stringer	Dialog_StairRamp_RailingPlaceOnHostDBar:Control_StairRamp_RailingPc	Contextual Tabs>Position
Edit Stairs	Dialog_StairRamp_EditStairsElementDialogBar:Control_StairRamp_EditSt	Contextual Tabs>Edit
Unsupported Object	Dialog_StairRamp_UnsupportedObjectWarnDbar:Control_StairRamp_Un:	Contextual Tabs>Warning
Edit	ID_DISPLACEMENT_EDIT	Contextual Tabs>Displacement Set
Reset	ID_DISPLACEMENT_RESET	Contextual Tabs>Displacement Set
Path	ID_DISPLACEMENT_PATH	Contextual Tabs>Displacement Set
Exit Revit	ID_APP_EXIT	Application Menu
Options	ID_OPTIONS	Application Menu
New; Project	ID_FILE_NEW_CHOOSE_TEMPLATE	Application Menu; Application Menu> New; Quick Access Toolbar
Family	ID_FAMILY_NEW	Application Menu> New
Conceptual Mass	ID_NEW_REVIT_DESIGN_MODEL	Application Menu> New
Title Block	ID_TITLEBLOCK_NEW	Application Menu> New
Annotation Symbol	ID_ANNOTATION_SYMBOL_NEW	Application Menu> New
Open; Revit file	ID_REVIT_FILE_OPEN	Application Menu; Application Menu> Open; Quick Access Toolbar
Project	ID_APPMENU_PROJECT_OPEN	Application Menu> Open
Family	ID_FAMILY_OPEN	Application Menu> Open
Building Component	ID_OPEN_ADSK	Application Menu> Open
IFC	ID_IMPORT_IFC	Application Menu> Open
IFC Options	ID_IFC_IMPORT_OPTIONS	Application Menu> Open
Sample Files	ID_SAMPLES_OPEN	Application Menu> Open
Save	ID_REVIT_FILE_SAVE	Application Menu; Quick Access Toolbar
Project	ID_REVIT_FILE_SAVE_AS	Application Menu> Save As
Family	ID_REVIT_SAVE_AS_FAMILY	Application Menu> Save As
Template	ID_REVIT_SAVE_AS_TEMPLATE	Application Menu> Save As
Family	ID_SAVE_FAMILY_ANY	Application Menu> Save As >Library
Group	ID_SAVE_GROUP	Application Menu> Save As >Library
View	ID_SAVE_VIEWS_TO_FILE	Application Menu> Save As >Library
DWG	ID_EXPORT_DWG	Application Menu> Export >CAD Formats
DXF	ID_EXPORT_DXF	Application Menu> Export >CAD Formats
DGN	ID_EXPORT_DGN	Application Menu> Export >CAD Formats

ACIS (SAT)	ID_EXPORT_SAT	Application Menu> Export >CAD Formats
DWF/DWFX	ID_EXPORT_DWF	Application Menu> Export
Building Site	ID_SITE_BUILDING_SITE_EXPORT	Application Menu> Export
FBX	ID_EXPORT_FBX	Application Menu> Export
Family Types; Export Types...	ID_EXPORT_FAM_TYPES	Application Menu> Export
gbXML	ID_ABS_EXPORT_GBXML	Application Menu> Export
Mass Model gbXML	ID_CEA_EXPORT_GBXML	Application Menu> Export
IFC	ID_EXPORT_IFC	Application Menu> Export
ODBC Database	ID_FILE_EXPORT_ODBC	Application Menu> Export
Walkthrough	ID_RM_ANIMATION	Application Menu> Export >Images and Animations
Solar Study	ID_FILE_EXPORT_SOLAR_STUDY	Application Menu> Export >Images and Animations
Image	ID_FILE_PRINT_TO_IMAGE	Application Menu> Export >Images and Animations
Schedule	ID_FILE_EXPORT_SCHEDULE	Application Menu> Export >Reports
Room/Area Report	ID_ROOM_AREA_REPORT	Application Menu> Export >Reports
Export Setups DWG/DXF	ID_SETTINGS_EXPORT_SETUPS_DWGDXF	Application Menu> Export >Options
Export Setups DGN	ID_SETTINGS_EXPORT_SETUPS_DGN	Application Menu> Export >Options
IFC Options	ID_IFC_OPTIONS	Application Menu> Export >Options
Publish; DWG to Autodesk Buzzsaw	ID_POSTTOBUZZSAW_DWF	Application Menu; Application Menu> Publish
DWG to Autodesk Buzzsaw	ID_POSTTOBUZZSAW_DWG	Application Menu> Publish
DXF to Autodesk Buzzsaw	ID_POSTTOBUZZSAW_DXF	Application Menu> Publish
DGN to Autodesk Buzzsaw	ID_POSTTOBUZZSAW_DGN	Application Menu> Publish
SAT to Autodesk Buzzsaw	ID_POSTTOBUZZSAW_SAT	Application Menu> Publish
Print	ID_REVIT_FILE_PRINT	Application Menu; Application Menu> Print
Print Preview	ID_REVIT_FILE_PRINT_PREVIEW	Application Menu> Print
Print Setup	ID_REVIT_FILE_PRINT_SETUP	Application Menu> Print
License Information	ID_LICENSE_INFO	Application Menu> Licensing
Close	ID_REVIT_FILE_CLOSE	Application Menu
Undo	ID_BUTTON_UNDO	Quick Access Toolbar
Redo	ID_BUTTON_REDO	Quick Access Toolbar
Help F1	ID_HELP_FINDER	Help
What's New?	ID_HELP_NEWS	Help
Essential Skills Videos	ID_HELP_ESSENTIAL_VIDEOS	Help
Learning Paths	ID_HELP_LEARNING_PATHS	Help
Revit Community	ID_HELP_VIDEOS	Help
Mosaic Community Portal	ID_HELP_MOSAIC	Help
Support Knowledge Base	ID_HELP_SUPPORT_KNOWLEDGE_BASE	Help
Revit Web Content Library	ID_HELP_WEBCONTENTLIBURL	Help
Autodesk.com/revit	ID_HELP_PRODUCTURL	Help
Desktop Analytics	ID_HELP_DESKTOP_ANALYTICS	Help
Customer Involvement Program	ID_HELP_CUSTOMERIMPROVEMENTPROGRAM	Help
About Autodesk Revit Meridian	ID_APP_ABOUT	Help
Line:Tangent End Arc	ID_OBJECTS_CURVE_ARC_TAN	Contextual Tabs>Draw
Architectural Wall:Start-End-Radius Arc	ID_WALL_ARC_THREE_PNT	Contextual Tabs>Draw
Line:Start-End-Radius Arc	ID_OBJECTS_CURVE_ARC_THREE_PNT	Contextual Tabs>Draw
Orient to Back Right	ID_ORIENT_TO_BACK_RIGHT	View Cube
Help	ID_VIEWCUBE_HELP	View Cube
Endpoints	ID_SNAP_OVERRIDE_END	SE Snaps
Increase/Decrease Focal Length	ID_SET_FOCAL_LENGTH	Steering Wheel
Default:Fillet Arc	IDC_RADIO_ARC_FILLET	Contextual Tabs>Draw
Reset Front	ID_VIEWCUBE_RESET_FRONT	View Cube
Structural Wall:Circumscribed Polygon	ID_WALL_STRUCT_POLY_CIRCUMSCRIBED	Contextual Tabs>Draw
Graphic Override by Category in View: toggle ghost surface	ID_VIEW_OVERRIDE_CATEGORY_GHOST	VOG
Default:Ellipse	IDC_RADIO_FULL_ELLIPSE	Contextual Tabs>Draw
Save View	ID_NAVWHEEL_SAVEVIEW	Steering Wheel

Ray Trace	ID_IMAGE_INTERACTIVE_RAYTRACE	RY	View Control Bar
Truss:Line	ID_TRUSS_LINE		Contextual Tabs>Draw
Snap Off; Snaps Off	ID_SNAP_OVERRIDE_NO_SNAP	SO	Snaps
Decrease Walk Speed	ID_NAVWHEEL_DECREASEWALKSPEED		Steering Wheel
Structural Wall:Start-End-Radius Arc	ID_WALL_STRUCT_ARC_THREE_PNT		Contextual Tabs>Draw
Restore Temporary View Properties	ID_RESTORE_VIEW_PROPERTIES		View Control Bar
Lock to Selection	ID_VIEWCUBE_LOCK_SELECTION		View Cube
Select All Instances in Active Option: In Entire Project	ID_SEL_ALL_IN_PRJ_IN_OPTION		Context Menu
Structural Wall:Pick Faces	ID_WALL_STRUCT_PICK_FACES		Contextual Tabs>Draw
Hidden Line	ID_IMAGE_HIDDENLINE	HL	View Control Bar
Snap to Remote Objects	ID_SNAP_OVERRIDE_REMOTE	SR	Snaps
Structural Wall:Fillet Arc	ID_WALL_STRUCT_ARC_FILLET		Contextual Tabs>Draw
Line:Partial Ellipse	ID_OBJECTS_CURVE_ELLIPSE_PARTIAL		Contextual Tabs>Draw
Unlock 3D View	ID_LOCKUNLOCK3DVIEW_UNLOCK		View Control Bar
Default:Center-ends Arc	IDC_RADIO_ARC_CENTER		Contextual Tabs>Draw
Default:Inscribed Polygon	IDC_RADIO_INSCRIBED_POLYGON		Contextual Tabs>Draw
Undo View Orientation Changes	ID_NAVWHEEL_UNDOVIEWORIENTATIONCHANGES		Steering Wheel
Move Crop Boundary	ID_MOVE_CROP_BOUNDARY		Steering Wheel
Architectural Wall:Inscribed Polygon	ID_WALL_POLY_INSCRIBED		Contextual Tabs>Draw
Show Compass	ID_SHOW_COMPASS		View Cube
Make Worksets Editable	ID_MAKE_EDITABLE_PREFER_CHECKOUT		Context Menu
Set the center rotation to the default position	ID_DEFAULT_ROTATION_CENTER		Context Menu
Default:Start-End-Radius Arc	IDC_RADIO_ARC_3_PNT		Contextual Tabs>Draw
Graphic Display Options	ID_GRAPHIC_DISPLAY_OPTIONS	GD	View Control Bar
Restore Excluded Member	ID_ELEM_GROUP_EXCLUDED_MEMBER	RB	Context Menu
Structural Wall:Tangent End Arc	ID_WALL_STRUCT_ARC_TAN		Contextual Tabs>Draw
Orient to Other View	ID_ORIENT_TO_OTHER_VIEW		Steering Wheel
Close	ID_SNAP_OVERRIDE_CLOSE	SZ	Snaps
Select All Fabric in Host	ID_SELECT_IN_HOST_ALL_FABRIC		Context Menu
Show/Hide Analytical Model	ID_VIEW_FRAME_TOGGLE_ANALYTICAL_MODEL_VISIBILITY		View Control Bar
Isolate Element	ID_TEMPHIDE_ISOLATE	HI	View Control Bar
ArchWal:Pick Lines	ID_WALL_PICK_LINES		Contextual Tabs>Draw
Save Orientation and Lock 3D View	ID_LOCKUNLOCK3DVIEW_LOCKANDSAVE		View Control Bar
Orient to Top	ID_ORIENT_TO_TOP		View Cube
Shaded	ID_IMAGE_SHADING		View Control Bar
Orient to South Direction	ID_ORIENT_SOUTH_DIRECTION		View Cube
Architectural Wall:Circle	ID_WALL_CIRCLE		Contextual Tabs>Draw
New File Default Template 4	ID_FILE_NEW_WITH_TEMPLATE4		
Enable Temporary View Properties	ID_ENABLE_TEMPORARY_VIEW_PROPERTIES		View Control Bar
Turn Override Off	ID_SETTINGS_SNAPS_NOOVERRIDE	SS	Snaps
Default:Circumscribed Polygon	IDC_RADIO_CIRCUMSCRIBED_POLYGON		Contextual Tabs>Draw
Medium Detail	ID_DETAIL_LEVEL_MEDIUM		View Control Bar
Architectural Wall:Circumscribed Polygon	ID_WALL_POLY_CIRCUMSCRIBED		Contextual Tabs>Draw
Isolate Category	ID_TEMPHIDE_ISOLATECAT	IC	View Control Bar
Tangents	ID_SNAP_OVERRIDE_TANGENT	ST	Snaps
Select All Instances: Visible in View	ID_SEL_ALL_IN_VIEW		Context Menu
New File Default Template 3	ID_FILE_NEW_WITH_TEMPLATE3		
Zoom Out(2x)	ID_ZOOM_OUT_X2	ZO#ZV	Navigation Bar
Orient to Southeast Direction	ID_ORIENT_SOUTHEAST_DIRECTION		View Cube
Fly Mode	ID_NAVBAR_3DCONTROLLER_FLY	3F	Navigation Bar
Default:Circle	IDC_RADIO_CIRCLE		Contextual Tabs>Draw
Graphic Override by Category in View: toggle transparency	ID_VIEW_OVERRIDE_CATEGORY_TRANSPARENT	VOT	
Object Mode	ID_NAVBAR_3DCONTROLLER_OBJECT	3O	Navigation Bar
Line:Circumscribed Polygon	ID_OBJECTS_CURVE_POLY_CIRCUMSCRIBED		Contextual Tabs>Draw

Centers	ID_SNAP_OVERRIDE_CENTER	SC	Snaps
Find Referring views	ID_FIND_VIEW_GENERATOR		Context Menu
Orient to North Direction	ID_ORIENT_NORTH_DIRECTION		View Cube
Toggle Highlight Displacement Sets	Control_Revit_ExplodedViewMode		View Control Bar
Midpoints	ID_SNAP_OVERRIDE_MID	SM	Snaps
Level Camera	ID_NAVWHEEL_LEVELCAMERA		Steering Wheel
Line:Fillet Arc	ID_OBJECTS_CURVE_ARC_FILLET		Contextual Tabs>Draw
Exclude	ID_EXCLUDE_GROUP_MEMBERS	EX	Context Menu
Consistent Colors	ID_IMAGE_FLAT_COLORS		View Control Bar
Make Elements Editable	ID_MAKE_EDITABLE_BY_BORROWING		Context Menu
Mini Full Navigation Wheel	ID_NAVWHEEL_MINI_EIGHT_WHEEL		Steering Wheel
Coarse Detail	ID_DETAIL_LEVEL_COARSE		View Control Bar
Close	ID_NAVWHEEL_CLOSE		Steering Wheel
Options	ID_NAVWHEEL_OPTIONS		Steering Wheel
Mini View Object Wheel	ID_NAVWHEEL_MINI_MINI_WHEEL		Steering Wheel
Graphic Override by Element in View: toggle ghost surface	ID_VIEW_OVERRIDE_ELEMENTS_GHOST	EOG	
Fine Detail	ID_DETAIL_LEVEL_FINE		View Control Bar
Temporarily Apply Template Properties	ID_TEMPORARILY_APPLY_TEMPLATE_PROPERTIES		View Control Bar
Shadows On	ID_IMAGE_SHADOW_ON		View Control Bar
Tour Building Wheel	ID_NAVWHEEL_INTERIOR_WHEEL		Steering Wheel
Next Pan/Zoom	ID_VIEW_ZOOMANDPAN_NEXTVIEW		Navigation Bar
WireFrame	ID_IMAGE_WIREFRAME	WF	View Control Bar
Orient to Left	ID_ORIENT_TO_LEFT		View Cube
Grid:Center-Ends Arc	ID_GRID_ARC_CENTER_ENDS		Contextual Tabs>Draw
StairRun:Line	ID_RUN_LINE		Contextual Tabs>Draw
Architectural Wall: Center-Ends Arc	ID_WALL_ARC_CENTER_ENDS		Contextual Tabs>Draw
Repeat Last Command	ID_REPEAT_LASTCOMMAND	RC	Context Menu
Structural Wall:Line	ID_WALL_STRUCT_LINE		Contextual Tabs>Draw
Mini Tour Building Wheel	ID_NAVWHEEL_MINI_OTHER_WHEEL		Steering Wheel
New File Default Template 5	ID_FILE_NEW_WITH_TEMPLATES5		
Default:Partial Ellipse	IDC_RADIO_PARTIAL_ELLIPSE		Contextual Tabs>Draw
Apply Hide/Isolate to View	ID_TEMPHIDE_MAKEPERM		View Control Bar
View Object Wheel	ID_NAVWHEEL_EXTERIOR_WHEEL		Steering Wheel
Realistic	ID_IMAGE_REALISTIC		View Control Bar
Line:Rectangle	ID_OBJECTS_CURVE_RECT		Contextual Tabs>Draw
Default:Tangent End Arc	IDC_RADIO_ARC_TAN_END		Contextual Tabs>Draw
Activate the first contextual tab	ID_ACTIVATE_CONTEXTUAL_TAB	Ctrl+`	
Line:Pick Existing Wall	ID_SKETCH_PICK_WALLS		Contextual Tabs>Draw
Line:Center-Ends Arc	ID_OBJECTS_CURVE_ARC_CENTER_ENDS		Contextual Tabs>Draw
Crop (Uncrop) View	IDC_VIEW_FRAME_CROPREGION_ACTIVITY		View Control Bar
Walk Mode	ID_NAVBAR_3DCONTROLLER_WALK	3W	Navigation Bar
Reset Temporary Hide/Isolate	ID_TEMPHIDE_RESET	HR	View Control Bar
Quadrants	ID_SNAP_OVERRIDE_QUADRANT	SQ	Snaps
Snap to Point Clouds	ID_SNAP_OVERRIDE_POINT_CLOUDS	PC	Snaps
Re-center Crop Boundary	ID_NAVWHEEL_RECENTERCROPBOUNDARY		Steering Wheel
Line:Line	ID_OBJECTS_CURVE_LINE		Contextual Tabs>Draw
Orient to Northeast Direction	ID_ORIENT_NORTHEAST_DIRECTION		View Cube
Orient to West Direction	ID_ORIENT_WEST_DIRECTION		View Cube
Zoom All to Fit	ID_ZOOM_ALL_ALL	ZA	Navigation Bar
Pan Active View	ID_PAN_VIEW		Navigation Bar
Orient to Right	ID_ORIENT_TO_RIGHT		View Cube
Shaded with Edges	ID_IMAGE_SHADING_WITH_EDGES	SD	View Control Bar
Grid:Start-End-Radius Arc	ID_GRID_ARC_THREE_PNT		Contextual Tabs>Draw
Graphic Override by Element in View: toggle halftone	ID_VIEW_OVERRIDE_ELEMENTS_HALFTONE	EOH	

Orient to Northwest Direction	ID_ORIENT_NORTHWEST_DIRECTION		View Cube
Default:Rectangle	IDC_RADIO_RECT		Contextual Tabs>Draw
Select Previous	ID_EDIT_SELECT_PREVIOUS		Context Menu
Set Current View as Home	ID_VIEWCUBE_SET_HOME		View Cube
Go Home	ID_VIEWCUBE_HOME		View Cube
Work Plane Grid	ID_SNAP_OVERRIDE_SKETCH_GRID	SW	Snaps
Structural Wall:Circle	ID_WALL_STRUCT_CIRCLE		Contextual Tabs>Draw
Orient to Top Direction	ID_ORIENT_TOP_DIRECTION		View Cube
Options	ID_VIEWCUBE_OPTIONS		View Cube
Points	ID_SNAP_OVERRIDE_POINT	SX	Snaps
Truss:Pick Lines	ID_TRUSS_PICK_LINES		Contextual Tabs>Draw
Select All Rebar in Host	ID_SELECT_IN_HOST_ALL_REBAR		Context Menu
Structural Wall:Inscribed Polygon	ID_WALL_STRUCT_POLY_INSCRIBED		Contextual Tabs>Draw
Zoom to Fit	ID_ZOOM_FIT	ZE#ZF#ZX	Navigation Bar
2D Mode	ID_NAVBAR_3DCONTROLLER_2D	32	Navigation Bar
Default:Line	IDC_RADIO_LINE		Contextual Tabs>Draw
Zoom in Region	ID_ZOOM_IN	ZR#ZZ	Navigation Bar
Architectural Wall:Tangent End Arc	ID_WALL_ARC_TAN		Contextual Tabs>Draw
Structural Wall:Center-Ends Arc	ID_WALL_STRUCT_ARC_CENTER_ENDS		Contextual Tabs>Draw
Orient to Southwest Direction	ID_ORIENT_SOUTHWEST_DIRECTION		View Cube
Architectural Wall:Rectangle	ID_WALL_RECT		Contextual Tabs>Draw
Select All Instances: In Entire Project	ID_SEL_ALL_IN_PRJ	SA	Context Menu
Show (Hide) Crop Region	IDC_VIEW_FRAME_CROPREGION_VISIBILITY		View Control Bar
Architectural Wall:Line	ID_WALL_LINE		Contextual Tabs>Draw
Full Navigation Wheel	ID_NAVWHEEL_FULL_WHEEL		Steering Wheel
Increase Walk Speed	ID_NAVWHEEL_INCREASEWALKSPEED		Steering Wheel
Line:Ellipse	ID_OBJECTS_CURVE_ELLIPSE		Contextual Tabs>Draw
StairRun:Center-Ends Arc	ID_RUN_ARC_CENTER_ENDS		Contextual Tabs>Draw
New File Default Template 2	ID_FILE_NEW_WITH_TEMPLATE2		
Restore Original Center	ID_NAVWHEEL_RESTOREORIGINALCENTER		Steering Wheel
Zoom Sheet Size	ID_ZOOM_SHEET	ZS	Navigation Bar
Move to Project	ID_MOVE_GROUP_MEMBER_TO_PROJECT	MP	Context Menu
Architectural Wall:Fillet Arc	ID_WALL_ARC_FILLET		Contextual Tabs>Draw
Orient to Front Left	ID_ORIENT_TO_FRONT_LEFT		View Cube
Orient to A Plane	ID_ORIENT_PLANE		View Cube
New File Default Template 1	ID_FILE_NEW_WITH_TEMPLATE1		
Define a new center of rotation	ID_DEFINE_ROTATION_CENTER	R3	Context Menu
Shadows Off	ID_IMAGE_SHADOW_OFF		View Control Bar
Grid:Line	ID_GRID_LINE		Contextual Tabs>Draw
Line:Spline	ID_OBJECTS_CURVE_SPLINE		Contextual Tabs>Draw
Fit to Window	ID_NAVWHEEL_FITWINDOW		Steering Wheel
Set Front to Current View	ID_SET_FRONT_TO_CURRENT_VIEW		View Cube
Orient to Front Right	ID_ORIENT_TO_FRONT_RIGHT		View Cube
Hide Element	ID_TEMPHIDE_HIDE	HH	View Control Bar
Line:Circle	ID_OBJECTS_CURVE_CIRCLE		Contextual Tabs>Draw
Help	ID_NAVWHEEL_HELP		Steering Wheel
Orient to Back	ID_ORIENT_TO_BACK		View Cube
Previous Pan/Zoom	ID_VIEW_ZOOMANDPAN_PREVIOUSVIEW	ZP#ZC	Navigation Bar
Properties	ID_SHOW_PROPERTIES_PALETTE		Context Menu
Graphic Override by Element in View: toggle transparency	ID_VIEW_OVERRIDE_ELEMENTS_TRANSPARENT	EOT	
Default:Pick Lines	IDC_RADIO_COPY_CURVE		Contextual Tabs>Draw
Default:Spline	IDC_RADIO_SPLINE		Contextual Tabs>Draw
Hide Category	ID_TEMPHIDE_HIDE CAT	HC	View Control Bar
Line:Inscribed Polygon	ID_OBJECTS_CURVE_POLY_INSCRIBED		Contextual Tabs>Draw

Orient to Front	ID_ORIENT_TO_FRONT		View Cube
Intersections	ID_SNAP_OVERRIDE_INTERSECT	SI	Snaps
Graphic Override by Category in View: toggle halftone	ID_VIEW_OVERRIDE_CATEGORY_HALFTONE	VOH	
Select All Instances in Active Option: Visible in View	ID_SEL_ALL_IN_VIEW_IN_OPTION		Context Menu
Select All Reinforcement in Host	ID_SELECT_IN_HOST_ALL_REINFORCEMENT		Context Menu
Structural Wall:Rectangle	ID_WALL_STRUCT_RECT		Contextual Tabs>Draw
Grid:Pick Lines	ID_GRID_PICK_LINES		Contextual Tabs>Draw
Orient to East Direction	ID_ORIENT_EAST_DIRECTION		View Cube
Restore Orientation and Lock 3D View	ID_LOCKUNLOCK3DVIEW_LOCKANDRESTORE		View Control Bar
Nearest	ID_SNAP_OVERRIDE_INTERIOR	SN	Snaps
Line:Pick Lines	ID_OBJECTS_CURVE_PICK_LINES		Contextual Tabs>Draw
Orient to Back Left	ID_ORIENT_TO_BACK_LEFT		View Cube
Structural Wall:Pick Lines	ID_WALL_STRUCT_PICK_LINES		Contextual Tabs>Draw
Perpendicular	ID_SNAP_OVERRIDE_PERP	SP	Snaps